

Software version TC4.1
FEBRUARY 2011



Administrator guide

For Cisco TelePresence System Quick Set C20 / C20 Plus and Profile 42" using C20

Thank you for choosing Cisco!

Your Cisco product has been designed to give you many years of safe, reliable operation.

This part of the product documentation is aimed at administrators working with the setup of the Quick Set C20 / C20 Plus and Profiles using Codec C20.

Our main objective with this Administrator guide is to address your goals and needs. Please let us know how well we succeeded!

May we recommend that you visit the Cisco web site regularly for updated versions of this guide.

The user documentation can be found on <http://www.cisco.com/go/telepresence/docs>.

How to use this guide

The top menu bar and the entries in the Table of Contents are all hyperlinks. Just click on them to go to the topic.

Table of Contents

Introduction

Introduction	5
User documentation	5
What's new in this version	6
Software release notes	6
Software download	6
User documentation	6
New features and improvements	6
Cisco TelePresence Touch for C Series	6
The Advanced configuration menu	7
New settings	7
Settings that have changed	7
Settings that have been removed	7
System overview	8
Profile 42" using Codec C20	8
Quick Set C20 / C20 Plus	9
Quick Set C20	9
Quick Set C20 Plus	9

Web interface

The web interface	11
Connect to the codec	11
Password protection of the web interface	11
Menu options	12
System information	13
Making calls from the web interface	14
Making a snapshot	15
User management	16
User roles	16
The default user account	16
Security mode	16
About password and PIN-code	17
Changing your password	18
Custom wallpaper	19
File format and picture size	19
Upload and activate the wallpaper	19

Adding a logon banner	20
Uploading certificates	21
Uploading the SSL certificate	21
Uploading the Trusted CA certificates list	21
Certificates for secure logging	22
About audit logging	22
Upload the Audit certificate list	22
Enable secure audit logging	22
Support log files	23
Historical log files	23
Current log files	23
Viewing XML files	24
Software upgrade	25
Advanced configuration	26
Restarting the system	27

Advanced configuration settings

Advanced configuration overview	29
The Audio settings	33
The Cameras settings	33
The Conference settings	35
The H323 settings	37
The Network settings	39
The NetworkServices settings	43
The Phonebook settings	46
The Provisioning settings	46
The Security settings	47
The SerialPort settings	48
The SIP settings	49
The Standby settings	50
The SystemUnit settings	51
The Time settings	52
The Video settings	53
The Experimental settings	59

Password protection

- Password protection 62
 - Set the Administrator settings menu password 62
 - Change your codec password 62
 - Change the user passwords 63
 - Set a root password 63

Appendices

- Connecting the Cisco TelePresence Touch controller to Codec C20 65
- About monitors when you have a Codec C20 66
 - Connecting the monitor 66
 - Connecting to HDMI 1 66
 - Connecting to HDMI 2 66
 - Moving the OSD using the remote control 66
 - Moving the OSD using the web interface 66
- Dual monitors 66
 - Dual monitor configuration 66
- Optimal definition profiles 67
- ClearPath – Packet loss resilience 68
- Requirement for speaker systems connected to a Cisco TelePresence C Series codec 69
- Codec C20 – The physical interface 70
 - The front panel LEDs 70
 - The rear panel 71
 - Pin-out schemes 72
- Quick Set C20 – Cable configuration 73
- Quick Set C20 Plus – Cable configuration 74
- DNAM for Profile 42" 75
 - The DNAM Loudspeaker 75
 - The DNAM Amplifier 75
- Technical specifications 76
 - Quick Set C20/C20 Plus 76
 - Profile 42" using C20 78

Chapter 1

Introduction

Introduction

This document provides you with the information required to administrate your product at an advanced level.

Products covered in this guide:

- Profile 42" using C20
- Quick Set C20 / C20 Plus

User documentation

The user documentation for the Cisco TelePresence systems, running the **TC software**, has several guides suitable for various user groups.

- Video conference room primer
- Video conference room acoustics guidelines
- Installation guides for the TelePresence systems
- Software release notes for the TC software
- Getting started guide for the TelePresence systems
- User guide for the TelePresence systems
 - When using the Touch controller, ref. TC4.1 version of the user guide
 - When using the Remote Control, ref. TC4.0 version of the user guide
- Quick reference guides for the TelePresence systems
- Administrator guides for the TelePresence systems
- Camera user guide for the PrecisionHD cameras
- API reference guides for the Codec C Series
- TC Console user guide for the Codec C Series
- Physical interfaces guides for the Codec C Series
- Regulatory compliance and safety information guides
- Legal & license information for products using TC software

Download the user documentation

Go to: ► <http://www.cisco.com/go/telepresence/docs>,
in the right pane, select:

- ***TelePresence Multipurpose Endpoints*** for the Profile Series.
- ***TelePresence Peripherals*** for the PrecisionHD cameras, microphones, Touch unit, and remote controls.
- ***TelePresence Solutions Platform*** for the Codec C Series and Quick Set C20.

What's new in this version

This section provides an overview of the new and changed API commands and new features in the TC4.1.0 software version.

Software release notes

For a complete overview of the news and changes, we recommend reading the Software Release Notes (TC4).

Go to: ► http://www.cisco.com/en/US/products/ps11422/tsd_products_support_series_home.html

Software download

For software download go to: ► <http://www.cisco.com/cisco/software/navigator.html?a=a&i=rpm>

User documentation

Go to: ► <http://www.cisco.com/go/telepresence/docs>, in the right pane, select:

- **TelePresence Multipurpose Endpoints** for the Profile Series.
- **TelePresence Peripherals** for the PrecisionHD cameras, microphones, Touch unit, and remote controls.
- **TelePresence Solutions Platform** for the Codec C Series and Quick Set C20.

New features and improvements

Cisco TelePresence Touch for C Series

The Cisco TelePresence Touch is a touch based user interface that supports Cisco's vision for a natural user experience.

You can make video calls, share content, and access some advanced features – all with a simple tap of the finger.



The Cisco TelePresence Touch is now available for:

- Cisco TelePresence System Codec C Series (C40, C60, C90)
- Cisco TelePresence System Profile Series using Codec C Series
- Cisco TelePresence System Quick Set C20

NOTE: Cisco TelePresence Touch for C Series requires software version TC4.1.0 or later.

Supported features:

- Calling
- Call control
- Conferencing
- Presenting
- Presentation source selection
- Layout handling
- Directory handling
- Favorites list
- Call history management
- Basic system configuration
- Basic presence control
- Camera control
 - Limited to one camera
 - Excluding camera presets
- Far end camera control on MultiSite (MultiSite is not supported on Quick Set C20)
- Volume control
- Microphone mute control
- EMC resilience mode
- All in one “search and dial” mechanism
- Provisioning of system settings and phonebook is supported. Provisioning of software upgrade is not supported in this release
- Password protection of the Administrator Settings

The Administrator Settings menu on the Touch controller can be password protected. This is done from a command line interface with an API (Application Programmer Interface) command. The password protection options are described in the C Series administrator guides.

NOTE: When using the touch controller most of the system configuration is done from the web interface. The web interface is described in the C Series administrator guides.

The Cisco TelePresence Touch for C Series can be connected to the C20 codec over LAN.

The Advanced configuration menu

New settings

Video Input Source [1..2] Type

Settings that have changed

Provisioning Mode

- Added argument "VCS"

Video SelfviewPosition

- Added argument "CenterRight"

Settings that have been removed

SystemUnit Type

Experimental settings

The Experimental settings are beta settings. These settings can be used 'as is', and are not fully documented.

NOTE: The Experimental settings are likely to change.

New settings:

Experimental NetworkServices UPnP Mode

Experimental NetworkServices UPnP Timeout

Experimental SystemUnit MenuType

System overview

Profile 42" using Codec C20

See the installation sheet for your Profile system for instructions on how to install the system.

Codec C20

- Full HD video.
- High resolution data sharing.
- Rich I/O capabilities.

PrecisionHD 1080p camera

Full HD Camera designed for visual communication with:

- 12 x optical zoom.
- Fast and precise pan, tilt and zoom.

Monitor

42" Full HD LCD, 16:9, 1080 x 1920 resolution.

Audio module

Wide band audio module supporting:

- 20 kHz AAC-LD.
- 1 echo canceller.

Audio amplifier

Optimized DNAM for the Profile system, providing crystal clear and natural audio.

Microphones

2 x Microphones.

Operating devices

Touch controller for C Series.

Remote control with AAA batteries.

Foot stand

Stand alone, wheelbase or wall mounting foot stand.



System overview, continued...

The Quick Set C20 packs the rich user experience of larger systems into a compact room based solution. Quick Set C20 is a high definition video collaboration system that has options for 1080p30 or 720p60 resolution, while being easy to deploy, simple to manage and intuitive to use. The Quick Set C20 is uniquely positioned to enable small scale deployment of a first time video solution, as well as allowing the enterprise scale an existing video conferencing solution to hundreds of locations throughout the entire organization.

Quick Set C20 / C20 Plus

Never before has the absolute quality of 1080p HD video been so accessible. The Quick Set C20 represents the first time a video solution with this quality and ease of use is available at a price point suited for small teams and those just starting out with video.

Quick Set C20

The Quick Set C20 includes a Codec C20, PrecisionHD 1080p 4X zoom camera, Performance Mic 20 and remote control. Simply add to any HD display and be ready to meet!

Quick Set C20 Plus

The Quick Set C20 Plus includes a Codec C20, PrecisionHD 1080p 12X zoom camera, Performance Mic 20 and remote control. Simply add to any HD display and be ready to meet!

Design features

- Transforms a flat panel display into a 1080p high definition meeting space.
- Simple, intuitive connections make setup as easy as connecting a DVD player.
- Quick Set C20 provides up to 1080p30 resolution with a 4x zoom camera.
- Quick Set C20 Plus provides up to 1080p30 and 720p60 resolution with a 12x zoom camera.
- Standards-compliant 1080p solution – compatible with standards-based video without loss of features.
- Sleek, compact design.

Application features

- Share multimedia and presentations at the touch of a button.
- Basic API available over IP (Telnet or SSH).
- Dual-display option available.
- HD content sharing with 720p and WXGA.

Performance features

- Optimal definition up to 1080p30.
- H.323/SIP up to 6 Mbps.



* Available for a limited period of time.

Chapter 2

Web interface

The web interface

The web interface allows for remote administration of the system.

Connect to the codec

Open a web browser and enter the *IP address* of the codec.

How to find the IP address:

To find the IP address, open the System Information page using the remote control. Navigate to *Home > Settings > System Information*.

Password protection of the web interface

In order to access the web interface you must sign in. The username and password are the same as defined for the codec. The default username is *admin* with no password set.

Read more about password protecting your codec in the [Password protection](#) chapter.

Signing in

1. Enter the IP address of the codec.

2. Enter the username and password and press *Sign In*.

Menu options

You will find the interactive menus on the left hand side of the web interface. When you click a menu option, a corresponding web page will open.

The role of the logged in user determines which menu options are available. You can read more about user roles in the ► [User management](#) section.

The user name of the signed in user is always displayed in the upper right corner.

The table below shows which menu options are available for users having ADMIN, AUDIT or USER roles. Note that the default `admin` user holds all three roles.

	ADMIN	AUDIT	USER
System Information	✓	✓	✓
Call			✓
Snapshot	✓		
Users	✓		
Change Password	✓	✓	✓
Wallpaper	✓	✓	
Logon Banner	✓		
Upload Certificates	✓		
Audit Certificate		✓	
Logs	✓		
XML Files	✓		
Upgrade Software	✓		
Advanced Configuration	✓	✓	
Restart			✓
Sign Out	✓	✓	✓

The interactive menus

Interactive menu

Click on the menu items to access the pages. Which menu options are available depends on the role of the logged in user.

System information

You can find an overview of your video system set-up on the System Information page.

The System Information page

System Info

My Codec

System name: My Codec
 Product: Cisco TelePresence Codec C20
 IP address: 192.168.1.128
 Valid release key: Yes

Software version: TC4.1.0
 Module serial number: BA9876543210
 MAC address: 00:33:66:99:CC:FF
 Installed options: NaturalPresenter, PremiumResolution, HighDefinition, DualDisplay

H323

Number: 1234567
 ID: firstname.lastname@company.com
 Gatekeeper: 192.168.1.1
 Status: Registered

SIP

Address: sip.firstname.lastname@company.com
 Proxy: 192.168.1.1
 Status: Registered

Login Info

Last successful login: Tue Oct 26 15:05:08 2010
 Number of unsuccessful login attempts since last logon: 0
 Password expires in: Never

Security

Strong security mode: Disabled

Security information
 Information about the current security mode (strong security mode available for JTIC labeled devices).

Login information
 Information about recent login attempts and password expiry.

System information
 Information about system name, product type, software version, IP address, etc.

Making calls from the web interface

Sometimes, e.g. when you are configuring the system from a remote location, it is convenient to be able to make calls from the video system to ensure everything works as expected.

The Call page

	Transmit	Receive
• Audio		
Protocol	AACLD	AACLD
• Video		
Protocol	H264	H264
Resolution	1024x576@30p	352x288@23p
• Presentation		
Protocol	Off	Off
Resolution	N/A	N/A

Make a call

Input field: Enter one or more characters in the input field, until the name you want to call appears in the dynamic search list or, enter the complete name or number.

Dial: Press **Dial** to initiate the call.

Disconnect all: Press **Disconnect all** to end all calls.

Options: Click **Options** to change the bit rate for this call. Select the **Call rate** in the drop down list.

The call status page

The call status page appear when you make a call. Please allow for approximately 30 seconds after the call is up before checking call details.

You will find the following information on the call status page:

- Remote number
- Status: Connected
- Direction: Incoming/Outgoing
- Protocol: H323/SIP
- Transmit and receive call rates
- Encryption
- Audio: Transmit and receive protocols
- Video: Transmit and receive protocols and resolutions
- Presentation: Transmit and receive protocols and resolutions

Making a snapshot

When administering the video system from a remote location, you can use the web interface snapshot feature to check the view of the main video input source.

This feature is disabled by default. The feature can be enabled only when you have direct access to the codec, i.e. from the on screen menu or by using the command line interface via the codec serial data port.

Using the on screen menu


From the Advanced configuration menu, navigate to **Video > AllowWebSnapshots** and select **On** to enable the snapshot feature.

Using the command line interface

Enter the following command to enable the snapshot feature:


```
Video AllowWebSnapshots <Off/On>.
```

The Snapshot page



How to make a snapshot

1. Press **Get snapshot**. The snapshot will be displayed on the web interface.



User management

From this page you can manage the user accounts of your video system. You can create a new user, edit the details of an existing user, and delete a user.

User roles

You must assign one or more user roles to a user account. Three user roles, which possess different system rights, are defined:

- **ADMIN:** A user with ADMIN rights can create a new user and change all settings, except the security audit configurations. This user cannot upload audit certificates.
- **USER:** A user with USER rights can make calls and search the phonebook.
- **AUDIT:** A user with AUDIT rights can change the security audit configurations and upload audit certificates.

The roles ADMIN, USER and AUDIT have non-overlapping rights, but a user can be created with one or more roles to combine the rights of more than one role.

NOTE: It is very important that at least one user has ADMIN rights at all times.

The default user account

The system comes with a default user account. The user name is `admin` with no password set. The `admin` user has USER, ADMIN and AUDIT roles.

It is highly recommended to set a password for this user.

Security mode

If you have a JTIC labeled system, you can enable/disable the strong security mode from this page. Strong security mode sets very strict password requirements, and requires all users to change their password on next login..

The Users page

The system comes with `admin` as default user account. The `admin` user possesses USER, ADMIN and AUDIT roles.

User name
You can create as many user accounts as you like on your system.

User role(s)
Each user must have one or more roles.

User management, continued...

If you have ADMIN rights you can manage users as described on this page.

About password and PIN-code

The password is used to access the web interface and the command line interfaces (SSH, Telnet and serial port), while the PIN is used to access the on screen menus.

The Users page

System Information

Call

Snapshot

Users

Change Password

Wallpaper

Logon Banner

Upload Certificates

Audit Certificate

Logs

XML Files

Upgrade Software

Advanced Configuration

Restart

Sign Out

User management

- admin - ADMIN, USER, AUDIT
- user1 - USER

Create new user

Security mode

Enable strong security mode Disable strong security mode

Create a new user account

1. Press **Create new user**.
2. Fill in the Username, Password and PIN code, and select the user role(s) for this user account. As a default the user have to change the password and PIN code when signing in for the first time.
3. Set the **Status** to **Active** to activate the user.
4. Press **Save** to save the changes.

Edit user details

1. Select the name of an existing user to open the Editing user window.
2. Edit the details.
3. Press **Save** to save the changes or **Cancel** to go back one step without storing the information.

Deactivate a user account

1. Select the name of an existing user to open the Editing user window.
2. Set the **Status** to **Inactive**.
3. Press **Save** to save the changes.

Delete a user account

1. Select the name of the user to open the Editing user window.
2. Press **Delete**.


NOTE: Do not delete all users with ADMIN rights.

Changing your password

When you are signed in, you can change your own password. In the example to the right, the admin user is signed in.

NOTE: It is highly recommended to set a password for all users with ADMIN rights. The password is a string with 0-255 characters.

The Change Password page



Change your password

1. Enter your current password, your new password, and repeat the new password in the input fields.
If no password is set, leave the current password input field empty.
If you want to remove a password, leave the new password input fields empty.
2. Press **Change password** to change the password.

Custom wallpaper

If you want the company logo or a custom picture to be displayed on screen, you may very well use a custom wallpaper.

NOTE: If your video system has a touch screen controller, please note that the custom wall paper applies to the main screen only and will not appear on the touch screen controller. When you choose a new predefined wallpaper on the touch screen, it will appear on both screens and replace your custom wall paper.


File format and picture size

The picture file format for the custom wallpaper is PNG. The maximum size is 1920x1200pixels.

Upload and activate the wallpaper

First you have to upload the wallpaper file to the codec, then you must activate the wallpaper.

The Wallpaper page




Upload the custom wallpaper file

1. Press **Browse...** and locate the wallpaper file (.PNG).
2. Press **Upload** to save the file to the codec.
3. Refresh the web page to see the wallpaper you just uploaded.

Activate the new wallpaper

1. Move to the Advanced configuration page and enter `wallpaper` in the search field. From the drop down list, select **Custom**. The new wallpaper will be displayed on screen.
2. If the new wallpaper does not show on screen, you may have to toggle once between Wallpaper: **None** and **Custom** to make the change take effect.



Adding a logon banner

If the system administrator wants to provide initial information to all users, he can create a logon banner. A logon banner is a message that is displayed to the user before signing in.

The message will be shown, whether the user signs in using the menu system, the web interface or the command line interface.

The Logon Banner page

Add a logon banner

1. Enter the text message, which you want to present to the user prior to signing in, in the Logon Banner text area.
2. Press **Submit Changes** to activate the message.

Uploading certificates

The SSL certificate is a text file which verifies the authenticity of your codec. The certificate may be issued by a certificate authority (CA). Other parties can check this certificate before setting up communication with you.

The list of trusted CA certificates is a list containing the SSL certificates of all parties that you want your codec to trust.

The Upload Certificates page


Signed in : admin

- System Information
- Call
- Snapshot
- Users
- Change Password
- Wallpaper
- Logon Banner
- Upload Certificates**
- Audit Certificate
- Logs
- XML Files
- Upgrade Software
- Advanced Configuration
- Restart
- Sign Out

SSL Certificate

HTTPS certificate (PEM format):

Private key (PEM format):

Passphrase:

Trusted CA Certificates

Trusted CA list file (PEM format):

Uploading the SSL certificate

To install the SSL certificate, you will need the following:

- HTTPS certificate (.PEM format)
- Private key (.PEM format)
- Passphrase (optional)

Contact your system administrator to obtain the required files.

- Press **Browse...** and locate the HTTPS certificate file (.PEM format).
- Press **Browse...** and locate the Private key file (.PEM format)
- Enter the **Passphrase** (optional).
- Press **Upload** to upload the certificate to the codec.

Uploading the Trusted CA certificates list

To install the trusted CA certificates list, you will need the following:

- Trusted CA list file (.PEM format).

Contact your system administrator to obtain the required file.

- Press **Browse...** and locate the file with the Trusted CA list (.PEM format).
- Press **Upload** to upload the certificate to the codec.

D14637.05 Profile C20 and Quick Set C20 Administrator Guide TC4.1, February 2011.
Copyright © 2010-2011 Cisco Systems, Inc. All rights reserved.

21

www.cisco.com

Certificates for secure logging

If you want to use the ExternalSecure audit logging mode, you must upload a list of trusted audit certificates to the codec. This list covers all audit servers that your codec shall trust.

In the ExternalSecure audit logging mode audit logging information will only be sent to entities holding a valid audit certificate.

NOTE: You should always upload the audit certificate list before enabling secure audit logging.


About audit logging

Audit logging records all login activity and configuration changes on the codec.

Audit logging is disabled by default, and must be enabled using the on screen menu, the web interface or the command line interface.

There are three audit logging modes: Internal, External and ExternalSecure.

The Audit Certificate page



Upload the Audit certificate list

To install the audit certificate, you will need:

- Audit list file (.PEM format)

Contact your system administrator to obtain the required file.

- Press **Browse...** and locate the file with the audit list file (.PEM format).
- Press **Upload** to upload the certificate to the codec.

Enable secure audit logging

To enable secure audit logging using the web interface or on screen menu, go to Advanced Configuration and perform the following steps:

1. Navigate to **Security > Audit > Server** and enter the IP address of the audit server.
2. Navigate to **Security > Audit > Logging > Mode** and set it to ExternalSecure.

To enable secure audit logging using the command line interface, log in to the codec using SSH or Telnet and enter the following commands:

1. `Security Audit Server Address <ip address>`
2. `Security Audit Logging Mode ExternalSecure`

Support log files

The log files are Cisco specific debug files which may be requested by the Cisco support organization if you need technical support.

The Logs page

Historical log files

Time stamped historical log files. Select *Historical log files*, click on a file and follow the instructions in the dialog box to save the file.

Logs

[back](#)

Filename	Size (KB)	Last modified
log.tar.gz	328	Tue Oct 5 12:16:32 2010
log.tar.gz.0	230	Wed Sep 15 11:54:30 2010
log.tar.gz.1	405	Thu Sep 23 14:01:40 2010
log.tar.gz.2	385	Tue Sep 28 15:42:52 2010
log.tar.gz.3	328	Tue Oct 5 12:16:32 2010
log.tar.gz.4	595	Fri Jul 16 14:10:46 2010
log.tar.gz.5	182	Tue Aug 24 09:41:00 2010
log.tar.gz.6	45	Tue Aug 24 10:07:30 2010
log.tar.gz.7	114	Thu Aug 26 12:59:13 2010
log.tar.gz.8	375	Mon Sep 13 15:03:36 2010
log.tar.gz.9	12	Mon Sep 13 15:05:58 2010

Current log files

Time stamped event log files. Select *Current log files* and click on a text file to view the file. Right click on a file and follow the instructions in the dialog box to save the file.

Logs

[back](#)

Filename	Size (KB)	Last modified
all.log	6	Wed Nov 3 13:54:03 2010
all.log.first	513	Wed Nov 3 13:41:05 2010
all.log.previous	513	Wed Nov 3 13:41:05 2010
all.log.truncated	0	Wed Nov 3 13:41:05 2010
application.log	251	Wed Nov 3 13:42:59 2010
audio0.log	2	Wed Nov 3 13:02:36 2010
audio1.log	1	Wed Nov 3 12:40:20 2010
audio2.log	1	Wed Nov 3 12:40:20 2010
audio3.log	1	Wed Nov 3 12:40:20 2010
audio4.log	1	Wed Nov 3 12:40:20 2010
audio5.log	1	Wed Nov 3 12:40:20 2010

D14637.05 Profile C20 and Quick Set C20 Administrator Guide TC4.1, February 2011.
Copyright © 2010-2011 Cisco Systems, Inc. All rights reserved.

23

www.cisco.com

Viewing XML files

The XML files are structured in a hierarchy building up a database of information about the codec.

The XML Files page


Signed in : admin

- System Information
- Call
- Snapshot
- Users
- Change Password
- Wallpaper
- Logon Banner
- Upload Certificates
- Audit Certificate
- Logs
- XML Files**
- Upgrade Software
- Advanced Configuration
- Restart
- Sign Out

XML Files

- Configuration
- Status
- Command
- Directory
- Valuespace
- Documentation

Configuration

Select *Configuration* to see an overview of the system settings, which are controlled from the Advanced configuration menu, or from the API (Application Programmer Interface).

Directory

The *Directory* file will be described later.

Status

The *Status* information is constantly updated by the system to reflect system and process changes. The status information is normally monitored from the API.

Valuespace

Select *Valuespace* to see an overview of the value spaces.

Command

Select *Command* to see an overview of the commands available to instruct the system to perform an action. The commands are issued from the API.

Documentation

The *Documentation* file will be described later.

D14637.05 Profile C20 and Quick Set C20 Administrator Guide TC4.1, February 2011.
 Copyright © 2010-2011 Cisco Systems, Inc. All rights reserved.

24

www.cisco.com

Software upgrade

From this page you can do software upgrades and add a release key and option keys.

Software versions

The C series codecs are using the TC software.

NOTE: Contact your system administrator if you have questions about the software version.

Software release notes and upgrade files

Cisco recommends reading the software release notes before upgrading the software.

Go to: ► http://www.cisco.com/en/US/products/ps11422/tsd_products_support_series_home.html

For upgrade software download go to: ► <http://www.cisco.com/cisco/software/navigator.html?a=a&i=rpm>

Release key

The release key is required to be able to use any of the released software.

Contact your Cisco representative to obtain the release key.

Option key

An option key is required to activate any optional functionality, and you may have several option keys in your system. The options available are:

- Natural presenter
- Premium resolution
- High definition
- Dual display

Contact your Cisco representative to obtain the option key(s).

The Upgrade Software page



Add the release and option keys

Contact your Cisco representative to obtain the required key(s). If you will add both a release key and one or more option keys, the valid procedure will be:

1. Enter the **release key** and press **Add**.
The key format: "1TC001-1-0C22E348" (each system will have a unique key).
2. Enter the **option key** and press **Add**.
The key format: "1N000-1-AA7A4A09" (each system will have a unique key).
3. If you have more than one option key, add the remaining keys.

Upgrade the software on the codec

4. Before you can start the upgrade you must download the software upgrade file. The file format: "s52000tc4_0_0.pkg" (each software version has a unique file name).
5. Press **Browse...** and select the .PKG file.
6. Press the **Upgrade** button to start the installation.
7. Leave the system to allow the installation process to complete. You can follow the progress on this page. When the upgrade is successfully completed a message will appear. The installation process may take up to 30 minutes.

Advanced configuration

The web interface allows for remote administration of the system.

The Advanced configuration defines the system settings and are structured in a hierarchy, making up a database of system settings.

The system settings are further explained in the ► [Advanced configuration settings](#) chapter.

The Advanced Configuration page

Signed in : admin

- System Information
- Call
- Snapshot
- Users
- Change Password
- Wallpaper
- Logon Banner
- Upload Certificates
- Audit Certificate
- Logs
- XML Files
- Upgrade Software
- Advanced Configuration**
- Restart
- Sign Out

Advanced Configuration

- Audio
- Cameras
- Conference 1
- Experimental
- H323
- Network 1
- NetworkPort 2
- NetworkServices
- Phonebook
- Provisioning
- Security
- SerialPort
- SIP
- Standby
- SystemUnit
- Time
- Video

Select a menu item to see the system settings.

- Audio
 - Volume : 75
 - Input
 - Output
 - SoundsAndAlerts
 - RingVolume : 60
 - RingTone : Marbles
 - KeyT
 - Marbles
 - IceCrystals
 - Polaris
 - Alert
 - Discreet
 - Fantasy
 - Jazz
 - Nordic
 - Echo
 - Rhythmic
- Cameras
- Conference
- Experiment
- GPIO
- H323

The search functionality

When searching for words such as H323 or SIP, all settings beginning with these characters, including all settings below in the hierarchy, will show in the list.

Search: Enter as many characters as needed to get the desired result and press **Search** to initiate the search.

Clear: Press **Clear** to return to the main view.

Changing system settings

Edit: To change a value, click on the value to see the expanded view.

Value space: The value space is specified, either as a drop down list or as text, when you edit a value.


OK: Press **ok** to save the new value.

Cancel: Select **cancel** to leave without saving.

Restarting the system

Restarting the system takes a few minutes.

The Restart page



Restart

You may restart the system by clicking the restart button

Restarting the system

Press *Restart now*.

Chapter 3

Advanced configuration settings

Advanced configuration overview

In the following pages you will find a complete list of the system settings which are configured from the Advanced Configuration page on the web interface or from the Advanced configuration menu on screen - open the **Home** menu and go to: **Settings > Administrator settings > Advanced configuration**. The examples show either the default value or an example of a value

The Audio settings	33	The Conference settings	35
Audio SoundsAndAlerts KeyTones Mode.....	33	Conference [1..1] AutoAnswer Delay	36
Audio SoundsAndAlerts RingTone	33	Conference [1..1] AutoAnswer Mode	35
Audio SoundsAndAlerts RingVolume	33	Conference [1..1] AutoAnswer Mute	35
Audio Volume	33	Conference [1..1] DefaultCall Protocol	36
The Cameras settings	33	Conference [1..1] DefaultCall Rate	36
Cameras Camera [1..1] Backlight.....	33	Conference [1..1] DoNotDisturb Mode.....	36
Cameras Camera [1..1] Brightness Level.....	34	Conference [1..1] Encryption Mode.....	36
Cameras Camera [1..1] Brightness Mode	34	Conference [1..1] FarEndControl Mode.....	36
Cameras Camera [1..1] DHCP.....	34	Conference [1..1] FarEndControl SignalCapability	36
Cameras Camera [1..1] Flip	34	Conference [1..1] MaxReceiveCallRate	35
Cameras Camera [1..1] Focus Mode.....	35	Conference [1..1] MaxTransmitCallRate	35
Cameras Camera [1..1] Gamma Level.....	35	Conference [1..1] MicUnmuteOnDisconnect.....	36
Cameras Camera [1..1] Gamma Mode.....	35	Conference [1..1] PacketLossResilience Mode.....	37
Cameras Camera [1..1] IrSensor	34	Conference [1..1] VideoBandwidth MainChannel Weight	37
Cameras Camera [1..1] Mirror	33	Conference [1..1] VideoBandwidth Mode	37
Cameras Camera [1..1] Whitebalance Level	34	Conference [1..1] VideoBandwidth PresentationChannel Weight.....	37
Cameras Camera [1..1] Whitebalance Mode	34	The H323 settings	37
Cameras PowerLine Frequency	33	H323 NAT Address.....	37
		H323 NAT Mode	37
		H323 Profile [1..1] Authentication LoginName	39
		H323 Profile [1..1] Authentication Mode	39
		H323 Profile [1..1] Authentication Password.....	39
		H323 Profile [1..1] CallSetup Mode	38
		H323 Profile [1..1] Gatekeeper Address.....	38
		H323 Profile [1..1] Gatekeeper Discovery	38
		H323 Profile [1..1] H323Alias E164	38
		H323 Profile [1..1] H323Alias ID	38
		H323 Profile [1..1] PortAllocation	38

The Network settings	39
Network [1..1] Assignment	39
Network [1..1] DNS Domain Name	41
Network [1..1] DNS Server [1..5] Address	41
Network [1..1] IEEE8021X AnonymousIdentity	42
Network [1..1] IEEE8021X Eap Md5	42
Network [1..1] IEEE8021X Eap Peap	42
Network [1..1] IEEE8021X Eap TTLS	42
Network [1..1] IEEE8021X Identity	42
Network [1..1] IEEE8021X Mode	41
Network [1..1] IEEE8021X Password	42
Network [1..1] IPStack	39
Network [1..1] IPv4 Address	40
Network [1..1] IPv4 Gateway	40
Network [1..1] IPv4 SubnetMask	40
Network [1..1] IPv6 Address	40
Network [1..1] IPv6 Assignment	40
Network [1..1] IPv6 DHCPOptions	40
Network [1..1] IPv6 Gateway	40
Network [1..1] MTU	39
Network [1..1] QoS Diffserv Audio	41
Network [1..1] QoS Diffserv Data	41
Network [1..1] QoS Diffserv Signalling	41
Network [1..1] QoS Diffserv Video	41
Network [1..1] QoS Mode	40
Network [1..1] RemoteAccess Allow	42
Network [1..1] Speed	39
Network [1..1] TrafficControl Mode	42

The NetworkServices settings	43
NetworkServices H323 Mode	45
NetworkServices HTTP Mode	43
NetworkServices HTTPS Mode	43
NetworkServices HTTPS VerifyClientCertificate	44
NetworkServices HTTPS VerifyServerCertificate	44
NetworkServices Multiway Address	43
NetworkServices Multiway Protocol	43
NetworkServices NTP Address	45
NetworkServices NTP Mode	45
NetworkServices SIP Mode	45
NetworkServices SNMP CommunityName	44
NetworkServices SNMP Host [1..3] Address	44
NetworkServices SNMP Mode	44
NetworkServices SNMP SystemContact	44
NetworkServices SNMP SystemLocation	44
NetworkServices SSH AllowPublicKey	43
NetworkServices SSH Mode	43
NetworkServices Telnet Mode	43

The Phonebook settings	46
Phonebook Server [1..1] ID	46
Phonebook Server [1..1] Type	46
Phonebook Server [1..1] URL	46

The Provisioning settings	46
Provisioning ExternalManager Address	47
Provisioning ExternalManager Domain	47
Provisioning ExternalManager Path	47
Provisioning ExternalManager Protocol	47
Provisioning HttpMethod	46
Provisioning LoginName	46
Provisioning Mode	46
Provisioning Password	46

The Security settings	47
Security Audit Logging Mode	48
Security Audit OnError Action	47
Security Audit Server Address	47
Security Audit Server Port	47
Security Session InactivityTimeout	48

The SerialPort settings	48	The Video settings	53
SerialPort BaudRate	48	Video AllowWebSnapshots	53
SerialPort LoginRequired.....	48	Video DefaultPresentationSource	54
SerialPort Mode.....	48	Video Input DVI [2] Type	56
The SIP settings	49	Video Input Source [1..2] CameraControl Camerald	55
SIP Profile [1..1] Authentication [1..1] LoginName.....	50	Video Input Source [1..2] CameraControl Mode.....	55
SIP Profile [1..1] Authentication [1..1] Password	50	Video Input Source [1..2] Name	54
SIP Profile [1..1] DefaultTransport.....	49	Video Input Source [1..2] OptimalDefinition Profile.....	55
SIP Profile [1..1] Outbound	49	Video Input Source [1..2] OptimalDefinition Threshold60fps.....	56
SIP Profile [1..1] Proxy [1..4] Address	50	Video Input Source [1..2] Quality	55
SIP Profile [1..1] Proxy [1..4] Discovery.....	49	Video Input Source [1..2] Type.....	55
SIP Profile [1..1] TlsVerify	49	Video Input Source 1 Connector.....	54
SIP Profile [1..1] Type	49	Video Input Source 2 Connector.....	54
SIP Profile [1..1] URI.....	49	Video Layout LocalLayoutFamily	57
The Standby settings	50	Video Layout RemoteLayoutFamily	57
Standby BootAction.....	51	Video Layout ScaleToFrame	57
Standby Control.....	50	Video Layout ScaleToFrameThreshold	57
Standby Delay	50	Video Layout Scaling.....	56
Standby StandbyAction	51	Video MainVideoSource	54
Standby WakeupAction	50	Video Monitors	54
The SystemUnit settings	51	Video OSD InputMethod Cyrillic.....	58
SystemUnit CallLogging Mode	52	Video OSD InputMethod InputLanguage.....	58
SystemUnit ContactInfo Type.....	52	Video OSD LoginRequired.....	58
SystemUnit IrSensor Mode	51	Video OSD Mode.....	57
SystemUnit MenuLanguage	51	Video OSD MyContactsExpanded	58
SystemUnit Name.....	51	Video OSD Output.....	58
The Time settings	52	Video OSD TodaysBookings.....	57
Time DateFormat	53	Video Output HDMI [1..2] MonitorRole	56
Time TimeFormat	53	Video Output HDMI [1..2] OverscanLevel	56
Time Zone	52	Video Output HDMI [1..2] Resolution	56
		Video Selfview.....	53
		Video SelfviewPosition.....	53
		Video Wallpaper	54

The Experimental settings	59
Experimental CapsetFilter	59
Experimental Conference [1..1] PacketLossResilience ForwardErrorCorrection	59
Experimental Conference [1..1] PacketLossResilience RateAdaption.....	59
Experimental CustomSoftbuttons State [1..2] Softbutton [1..5] Type.....	59
Experimental CustomSoftbuttons State [1..2] Softbutton [1..5] Value	59
Experimental NetworkServices UPnP Mode.....	59
Experimental NetworkServices UPnP Timeout.....	59
Experimental SoftwareUpgrade Mode.....	59
Experimental SoftwareUpgrade ServerAddress	60
Experimental SystemUnit MenuType.....	60

The Audio settings

Audio SoundsAndAlerts KeyTones Mode

The system can produce a sound every time a key on the remote control is pressed.

Requires user role: USER

Value space: <On/Off>

On: There will be a sound indicator when pressing keys on the remote control.

Off: The key tone on the remote control is switched off.

Example: Audio SoundsAndAlerts KeyTones Mode: Off

Audio SoundsAndAlerts RingTone

Selects the ringtone for incoming calls.

Requires user role: USER

Value space: <Marbles/IceCrystals/Polaris/Alert/Discreet/Fantasy/Jazz/Nordic/Echo/Rhythmic>

Range: Select a tone from the list of ringtones.

Example: Audio SoundsAndAlerts RingTone: Jazz

Audio SoundsAndAlerts RingVolume

Sets the ring tone volume for an incoming call. The value goes in steps of 5 from 0 to 100 (from -34.5dB to 15dB). Volume 0 = Off.

Requires user role: USER

Value space: <0..100>

Range: Select a value from 0 to 100.

Example: Audio SoundsAndAlerts RingVolume: 50

Audio Volume

Set the volume on the loudspeaker. The value goes in steps of 5 from 0 to 100 (from -34.5dB to 15dB). Volume 0 = Off.

Requires user role: USER

Value space: <0..100>

Range: Select a value from 0 to 100.

Example: Audio Volume: 70

The Cameras settings

Cameras PowerLine Frequency

Applies to cameras supporting PowerLine frequency anti-flickering, i.e PrecisionHD 1080p cameras.

Requires user role: ADMIN

Value space: <Auto/50Hz/60Hz>

Auto: Set to Auto to enable power frequency auto detection in the camera.

50Hz/60Hz: Set to 50Hz or 60Hz.

Example: Cameras PowerLine Frequency: Auto

Cameras Camera [1..1] Backlight

The backlight functionality compensates for lights shining directly at the camera (usually the sun entering the window) to avoid a too dark image from the room.

Requires user role: ADMIN

Value space: <On/Off>

On: Turn on the camera backlight.

Off: Turn off the camera backlight.

Example: Cameras Camera 1 Backlight: Off

Cameras Camera [1..1] Mirror

With Mirror mode (horizontal flip) you can mirror the image on screen.

Requires user role: ADMIN

Value space: <Auto/On/Off>

Auto: When the camera is placed upside down the image is automatically mirrored. Use this setting with cameras that can be mounted upside down, and that can auto detect that the camera is mounted upside down.

On: See the selfview in mirror mode, e.g. the selfview is reversed and the experience of selfview is as seeing yourself in a mirror.

Off: See the selfview in normal mode, e.g. the experience of selfview is as seeing yourself as other people see you.

Example: Cameras Camera 1 Mirror: Off

Cameras Camera [1..1] Flip

With Flip mode (vertical flip) you can flip the image upside down.

Requires user role: ADMIN

Value space: <Auto/On/Off>

Auto: When the camera is placed upside down the image is automatically flipped upside down. Use this setting with cameras that can be mounted upside down, and that can auto detect that the camera is mounted upside down.

On: When set to On the video on screen is flipped. This setting is used with cameras that can be mounted upside down, but cannot auto detect that the camera is mounted upside down.

Off: Set to Off to display the video on screen the normal way.

Example: Cameras Camera 1 Flip: Off

Cameras Camera [1..1] DHCP

Applies to cameras which supports DHCP. The Cisco TelePresence PrecisionHD 1080p camera supports DHCP. The camera must be connected to a LAN. When set, the command enables support for SW upgrade of daisy chained cameras. It will enable the camera's DHCP function and force start of MAC and IP address retrieval. Remember to reset the DHCP when the camera is no longer connected to a LAN.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable DHCP in the camera. The camera is automatically re-booted. After re-boot the DHCP is started and the IP address will be retrieved. Run the command "xStatus Camera" for result.

Off: Set to Off will disable DHCP in the camera. NOTE: When camera is not connected to a LAN, this setting should be applied.

Example: Cameras Camera 1 DHCP: Off

Cameras Camera [1..1] IrSensor

The IR sensor LED is located in the front of the camera and flickers when the IR sensor is activated from the remote control. Both the Codec C Series and PrecisionHD camera have IR sensors, and only one of them needs to be enabled at the time.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable the IR sensor on the camera.

Off: Disable the IR sensor on the camera.

Example: Cameras Camera 1 IrSensor: On

Cameras Camera [1..1] Brightness Mode

Set the camera brightness mode.

Requires user role: ADMIN

Value space: <Auto/Manual>

Auto: The camera brightness is automatically set by the system.

Manual: Enable manual control of the camera brightness, e.g. the level of the brightness level setting will be used for the camera.

Example: Cameras Camera 1 Brightness Mode: Auto

Cameras Camera [1..1] Brightness Level

Set the brightness level. NOTE: Requires the Camera Brightness Mode to be set to Manual.

Requires user role: ADMIN

Value space: <1..31>

Range: Select a value from 1 to 31.

Example: Cameras Camera 1 Brightness Level: 1

Cameras Camera [1..1] Whitebalance Mode

Set the camera whitebalance mode.

Requires user role: ADMIN

Value space: <Auto/Manual>

Auto: When set to Auto, the camera will continuously adjust the whitebalance depending on the camera view.

Manual: Set to Manual to enable manual control of the camera whitebalance, e.g. the level of the whitebalance level setting will be used for the camera.

Example: Cameras Camera 1 Whitebalance Mode: auto

Cameras Camera [1..1] Whitebalance Level

Set the whitebalance level. NOTE: Requires the Camera Whitebalance Mode to be set to manual.

Requires user role: ADMIN

Value space: <1..16>

Range: Select a value from 1 to 16.

Example: Cameras Camera 1 Whitebalance Level: 1

Cameras Camera [1..1] Focus Mode

Set the camera focus mode.

Requires user role: ADMIN

Value space: <Auto/Manual>

Auto: When set to Auto the focus will be updated throughout the call. When moving the camera, the system will use auto focus for a few seconds to set the right focus of the new camera position. After a few seconds auto focus is turned off to prevent continuous focus adjustments of the camera.

Manual: Turn the autofocus off and adjust the camera focus manually.

Example: Cameras Camera 1 Focus Mode: Auto

Cameras Camera [1..1] Gamma Mode

Applies to cameras which supports gamma mode. The Gamma Mode setting enables for gamma corrections. Gamma describes the nonlinear relationship between image pixels and monitor brightness. The Cisco TelePresence PrecisionHD 720p camera supports gamma mode. The PrecisionHD 1080p camera does not support gamma mode.

Requires user role: ADMIN

Value space: <Auto/Manual>

Auto: Auto is the default and the recommended setting.

Manual: In severe light conditions, you may switch mode to manual and specify explicitly which gamma table to use by setting the Gamma Level.

Example: Cameras Camera 1 Gamma Mode: Auto

Cameras Camera [1..1] Gamma Level

By setting the Gamma Level you can select which gamma correction table to use. This setting may be useful in difficult lighting conditions, where changes to the brightness setting does not provide satisfactory results. NOTE: Requires the Gamma Mode to be set to Manual.

Requires user role: ADMIN

Value space: <0..7>

Range: Select a value from 0 to 7.

Example: Cameras Camera 1 Gamma Level: 0

The Conference settings

Conference [1..1] MaxTransmitCallRate

Specify the maximum transmit call rate to be used when placing or receiving calls.

Requires user role: ADMIN

Value space: <64..6000>

Range: Select a value from 64 to 6000 kbps.

Example: Conference 1 MaxTransmitCallRate: 6000

Conference [1..1] MaxReceiveCallRate

Specify the maximum receive call rate to be used when placing or receiving calls.

Requires user role: ADMIN

Value space: <64..6000>

Range: Select a value from 64 to 6000 kbps.

Example: Conference 1 MaxReceiveCallRate: 6000

Conference [1..1] AutoAnswer Mode

Set the AutoAnswer mode.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable AutoAnswer to let the system automatically answer all incoming calls.

Off: The incoming calls must be answered manually by pressing the OK key or the green Call key on the remote control.

Example: Conference 1 AutoAnswer Mode: Off

Conference [1..1] AutoAnswer Mute

Determine if the microphone shall be muted when an incoming call is automatically answered. NOTE: Requires the AutoAnswer Mode to be enabled.

Requires user role: ADMIN

Value space: <On/Off>

On: The incoming call will be muted when automatically answered.

Off: The incoming call will not be muted.

Example: Conference 1 AutoAnswer Mute: Off

Conference [1..1] AutoAnswer Delay

Define how long (in seconds) an incoming call has to wait before it is answered automatically by the system. NOTE: Requires the AutoAnswer Mode to be enabled.

Requires user role: ADMIN

Value space: <0..50>

Range: Select a value from 0 to 50 seconds.

Example: Conference 1 AutoAnswer Delay: 0

Conference [1..1] MicUnmuteOnDisconnect

Determine if the microphones should be unmuted automatically when all calls are disconnected. In a meeting room or other shared resource this could be done to prepare the system for the next user.

Requires user role: ADMIN

Value space: <On/Off>

On: Un-mute the microphones after the call is disconnected.

Off: If muted, let the microphones remain muted after the call is disconnected.

Example: Conference 1 MicUnmuteOnDisconnect: On

Conference [1..1] DoNotDisturb Mode

Determine if there should be an alert on incoming calls.

Requires user role: USER

Value space: <On/Off>

On: On: All incoming calls will be rejected, with no alert. The calling side will receive a busy signal when trying to call the codec. A message will display on screen, telling that Do not disturb is turned on, together with an option to turn off the Do not disturb. When turning off the Do not disturb mode you will see a list of the calls that have been rejected.

Off: The incoming calls will be alerted.

Example: DoNotDisturb Mode: Off

Conference [1..1] FarEndControl Mode

Lets you decide if the remote side (far end) should be allowed to select your video sources and control your local camera (pan, tilt, zoom).

Requires user role: ADMIN

Value space: <On/Off>

On: Set to On when you want the far end to be able to select your video sources and control your local camera (pan, tilt, zoom). You will still be able to control your camera and select your video sources as normal.

Off: When set to Off the far end can not access any of the features above on your system.

Example: Conference 1 FarEndControl Mode: On

Conference [1..1] FarEndControl SignalCapability

Set the far end control (H.224) signal capability mode.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable the far end control signal capability.

Off: Disable the far end control signal capability.

Example: Conference 1 FarEndControl SignalCapability: On

Conference [1..1] Encryption Mode

Set the conference encryption mode. A padlock with the text "Encryption On" or "Encryption Off" displays on screen, for a few seconds, when the conference starts.

Requires user role: ADMIN

Value space: <BestEffort/On/Off>

BestEffort: The system will use encryption whenever possible.

> **In Point to point calls:** If the far end system supports encryption (AES-128), the call will be encrypted. If not, the call will proceed without encryption.

> **In MultiSite calls:** In order to have encrypted MultiSite conferences, all sites must support encryption. If not, the conference will be unencrypted.

On: The system will only allow calls that are encrypted.

Off: The system will not use encryption.

Example: Conference 1 Encryption Mode: BestEffort

Conference [1..1] DefaultCall Protocol

Set the Default Call Protocol to be used when placing calls from the system.

Requires user role: ADMIN

Value space: <H323/SIP>

H.323: Select H.323 to ensure that calls are set up as H.323 calls.

SIP: Select SIP to ensure that calls are set up as SIP calls.

Example: Conference 1 DefaultCall Protocol: H323

Conference [1..1] DefaultCall Rate

Set the Default Call Rate to be used when placing calls from the system.

Requires user role: ADMIN

Value space: <64..6000>

Range: 64-6000kbps

Example: Conference 1 DefaultCall Rate: 768

Conference [1..1] VideoBandwidth Mode

Set the conference video bandwidth mode.

Requires user role: ADMIN

Value space: <Dynamic/Static>

Dynamic: The available transmit bandwidth for the video channels are distributed among the currently active channels. If there is no presentation, the main video channels will use the bandwidth of the presentation channel.

Static: The available transmit bandwidth is assigned to each video channel, even if it is not active.

Example: Conference 1 VideoBandwidth Mode: Dynamic

Conference [1..1] VideoBandwidth MainChannel Weight

The available transmit video bandwidth is distributed on the main channel and presentation channel according to "MainChannel Weight" and "PresentationChannel Weight". If the main channel weight is 2 and the presentation channel weight is 1, then the main channel will use twice as much bandwidth as the presentation channel.

Requires user role: ADMIN

Value space: <1..10>

Range: 1 to 10.

Example: Conference 1 VideoBandwidth MainChannel Weight: 5

Conference [1..1] VideoBandwidth PresentationChannel Weight

The available transmit video bandwidth is distributed on the main channel and presentation channel according to "MainChannel Weight" and "PresentationChannel Weight". If the main channel weight is 2 and the presentation channel weight is 1, then the main channel will use twice as much bandwidth as the presentation channel.

Requires user role: ADMIN

Value space: <1..10>

Range: 1 to 10.

Example: Conference 1 VideoBandwidth PresentationChannel Weight: 5

Conference [1..1] PacketLossResilience Mode

Set the packetloss resilience mode. This configuration will only take effect for calls initiated after the configuration is set.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable the packetloss resilience.

Off: Disable the packetloss resilience.

Example: Conference 1 PacketLossResilience Mode: On

The H323 settings

H323 NAT Mode

The firewall traversal technology creates a secure path through the firewall barrier, and enables proper exchange of audio/video data when connected to an external video conferencing system (when the IP traffic goes through a NAT router). NOTE: NAT does not work in conjunction with gatekeepers.

Requires user role: ADMIN

Value space: <Auto/On/Off>

Auto: The system will determine if the "NAT Address" or the real IP-address should be used within signalling. This is done to make it possible to place calls to endpoints on the LAN as well as endpoints on the WAN.

On: The system will signal the configured "NAT Address" in place of its own IP-address within Q.931 and H.245. The NAT Server Address will be shown in the startup-menu as: "My IP Address: 10.0.2.1".

Off: The system will signal the real IP Address.

Example: H323 NAT Mode: Off

H323 NAT Address

Enter the external/global IP-address to the router with NAT support. Packets sent to the router will then be routed to the system.

In the router, the following ports must be routed to the system's IP-address:

- * Port 1720
- * Port 5555 to 5574
- * Port 2326 to 2485

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: H323 NAT Address: ""

H323 Profile [1..1] PortAllocation

The H.323 Port Allocation setting affects the H.245 port numbers used for H.323 call signalling.

Requires user role: ADMIN

Value space: <Dynamic/Static>

Dynamic: The system will allocate which ports to use when opening a TCP connection. The reason for doing this is to avoid using the same ports for subsequent calls, as some firewalls consider this as a sign of attack. When Dynamic is selected, the H.323 ports used are from 11000 to 20999. Once 20999 is reached they restart again at 11000. For RTP and RTCP media data, the system is using UDP ports in the range 2326 to 2487. Each media channel is using two adjacent ports, ie 2330 and 2331 for RTP and RTCP respectively. The ports are automatically selected by the system within the given range. Firewall administrators should not try to deduce which ports are used when, as the allocation schema within the mentioned range may change without any further notice.

Static: When set to Static the ports are given within a static predefined range [5555 to 6555].

Example: H323 Profile 1 PortAllocation: Dynamic

H323 Profile [1..1] H323Alias ID

Lets you specify the H.323 Alias ID which is used to address the system on a H.323 Gatekeeper and will be displayed in the call lists. Example: "firstname.surname@company.com", "My H.323 Alias ID"

Requires user role: ADMIN

Value space: <S: 0, 49>

Format: String with a maximum of 49 characters

Example: H323 Profile 1 H323Alias ID: "firstname.surname@company.com"

H323 Profile [1..1] H323Alias E164

The H.323 Alias E.164 defines the address of the system, according to the numbering plan implemented in the H.323 Gatekeeper. The E.164 alias is equivalent to a telephone number, sometimes combined with access codes.

Requires user role: ADMIN

Value space: <S: 0, 30>

Format: Compact string with a maximum of 30 characters. Valid characters are 0 to 9, * and #.

Example: H323 Profile 1 H323Alias E164: "90550092"

H323 Profile [1..1] CallSetup Mode

The H.323 Call Setup Mode defines whether to use a Gatekeeper or Direct calling when establishing H323 calls.

NOTE: Direct H.323 calls can be made even though the H.323 Call Setup Mode is set to Gatekeeper.

Requires user role: ADMIN

Value space: <Direct/Gatekeeper>

Direct: An IP-address must be used when dialling in order to make the H323 call.

Gatekeeper: The system will use a Gatekeeper to make a H.323 call. When selecting this option the H323 Profile Gatekeeper Address and H323 Profile Gatekeeper Discovery settings must also be configured.

Example: H323 Profile 1 CallSetup Mode: Gatekeeper

H323 Profile [1..1] Gatekeeper Address

Enter the IP address of the Gatekeeper. NOTE: Requires the H.323 Call Setup Mode to be set to Gatekeeper and the Gatekeeper Discovery to be set to Manual.

Requires user role: ADMIN

Value space: <S: 0, 255>

Format: Only the valid IP address format is accepted. An IP address that contains letters (192.a.2.0) or invalid IP addresses (192.0.1234.0) will be rejected.

Example: H323 Profile 1 Gatekeeper Address: "192.0.2.0"

H323 Profile [1..1] Gatekeeper Discovery

Determine how the system shall register to a H.323 Gatekeeper.

Requires user role: ADMIN

Value space: <Manual/Auto>

Manual: The system will use a specific Gatekeeper identified by the Gatekeeper's IP-address.

Auto: The system will automatically try to register to any available Gatekeeper. If a Gatekeeper responds to the request sent from the codec within 30 seconds this specific Gatekeeper will be used. This requires that the Gatekeeper is in auto discovery mode as well. If no Gatekeeper responds, the system will not use a Gatekeeper for making H.323 calls and hence an IP-address must be specified manually.

Example: H323 Profile 1 Gatekeeper Discovery: Manual

H323 Profile [1..1] Authentication LoginName

The system sends the Authentication Login Name and the Authentication Password to a H.323 Gatekeeper for authentication. The authentication is a one way authentication from the codec to the H.323 Gatekeeper, i.e. the system is authenticated to the gatekeeper. If the H.323 Gatekeeper indicates that no authentication is required, the system will still try to register. NOTE: Requires the H.323 Gatekeeper Authentication Mode to be enabled.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: H323 Profile 1 Authentication LoginName: ""

H323 Profile [1..1] Authentication Password

The system sends the Authentication Login Name and the Authentication Password to a H.323 Gatekeeper for authentication. The authentication is a one way authentication from the codec to the H.323 Gatekeeper, i.e. the system is authenticated to the gatekeeper. If the H.323 Gatekeeper indicates that no authentication is required, the system will still try to register. NOTE: Requires the H.323 Gatekeeper Authentication Mode to be enabled.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: H323 Profile 1 Authentication Password:

H323 Profile [1..1] Authentication Mode

Set the authenticatin mode for the H.323 profile.

Requires user role: ADMIN

Value space: <On/Off>

On: If the H.323 Gatekeeper Authentication Mode is set to On and a H.323 Gatekeeper indicates that it requires authentication, the system will try to authenticate itself to the gatekeeper. NOTE: Requires the Authentication LoginName and Authentication Password to be defined on both the codec and the Gatekeeper.

Off: If the H.323 Gatekeeper Authentication Mode is set to Off the system will not try to authenticate itself to a H.323 Gatekeeper, but will still try a normal registration.

Example: H323 Profile 1 Authentication Mode: Off

The Network settings

Network [1..1] Speed

Set the Ethernet link speed.

Requires user role: ADMIN

Value space: <Auto/10half/10full/100half/100full/1000full>

Auto: Autonegotiate link speed.

10half: Force link to 10Mbps half-duplex.

10full: Force link to 10Mbps full-duplex.

100half: Force link to 100Mbps half-duplex.

100full: Force link to 100Mbps full-duplex.

1000full: Force link to 1Gbps full-duplex.

Example: Network 1 Speed: Auto

Network [1..1] Assignment

Define whether to use DHCP or Static IPv4 assignment.

Requires user role: ADMIN

Value space: <Static/DHCP>

Static: Set the network assignment to Static and configure the static IPv4 settings (IP Address, SubnetMask and Gateway).

DHCP: The system addresses are automatically assigned by the DHCP server.

Example: Network 1 Assignment: DHCP

Network [1..1] IPStack

Select which internet protocols the system will support.

Requires user role: ADMIN

Value space: <IPv4/IPv6>

IPv4: IP version 4 is supported.

IPv6: IP version 6 is supported. The IPv4 settings (IP Address, IP Subnet Mask and Gateway) will be disabled.

Example: Network 1 IPStack: IPv4

Network [1..1] MTU

Set the Ethernet MTU (Maximum Transmission Unit).

Requires user role: ADMIN

Value space: <400..1500>

Range: Select a value from 400 to 1500 bytes.

Example: Network 1 MTU: 1500

Network [1..1] IPv6 Address

Enter the static IPv6 network address for the system. Only applicable if the Network IPv6 Assignment is set to Static.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: The IPv6 address of host name.

Example: Network 1 IPv6 Address: "ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff"

Network [1..1] IPv6 Gateway

Define the IPv6 network gateway address. Only applicable if the Network IPv6 Assignment is set to Static.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: The IPv6 address of host name.

Example: Network 1 IPv6 Gateway: "ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff"

Network [1..1] IPv6 Assignment

Define whether to use Autoconf or Static IPv6 assignment.

Requires user role: ADMIN

Value space: <Static/Autoconf>

Static: Set the network assignment to Static and configure the static IPv6 settings (IP Address and Gateway).

Autoconf: Enable IPv6 stateless autoconfiguration of the IPv6 network interface. See RFC4862 for a detailed description.

Example: Network 1 IPv6 Assignment: Autoconf

Network [1..1] IPv6 DHCPOptions

Retrieves a set of DHCP options from a DHCPv6 server.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable the retrieval of a selected set of DHCP options from a DHCPv6 server.

Off: Set to Off when IPv6 Assignment is set to Static.

Example: Network 1 IPv6 Gateway: On

Network [1..1] IPv4 Address

Enter the static IP network address for the system. Only applicable if the Network Assignment is set to Static.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: Only the valid IP address format is accepted. An IP address that contains letters (192.a.2.0) or invalid IP addresses (192.0.1234.0) will be rejected.

Example: Network 1 IPv4 Address: "192.0.2.0"

Network [1..1] IPv4 SubnetMask

Define the IP network subnet mask. Only applicable if the Network Assignment is set to Static.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: Compact string with a maximum of 64 characters.

Example: Network 1 IPv4 SubnetMask: "255.255.255.0"

Network [1..1] IPv4 Gateway

Define the IP network gateway. Only applicable if the Network Assignment is set to Static.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: Compact string with a maximum of 64 characters.

Example: Network 1 IPv4 Gateway: "192.0.2.0"

Network [1..1] QoS Mode

The QoS (Quality of Service) is a method which handles the priority of audio, video and data in the network. The QoS settings must be supported by the infrastructure. Diffserv (Differentiated Services) is a computer networking architecture that specifies a simple, scalable and coarse-grained mechanism for classifying, managing network traffic and providing QoS priorities on modern IP networks.

Requires user role: ADMIN

Value space: <Off/Diffserv>

Off: No QoS method is used.

Diffserv: When you set the QoS Mode to Diffserv you must configure the Diffserv sub menu settings (Audio, Data, Signalling and Video).

Example: Network 1 QoS Mode: diffserv

Network [1..1] QoS Diffserv Audio

The Diffserv Audio defines which priority Audio packets should have in an IP network. Enter a priority, which ranges from 0 to 63 for the packets. The higher the number, the higher the priority. These priorities might be overridden when packets are leaving the network controlled by the local network administrator. NOTE: Requires the Network QoS Mode to be set to Diffserv.

Requires user role: ADMIN

Value space: <0..63>

Audio: A recommended value is Diffserv Code Point (DSCP) AF41, which equals the value 34. If in doubt, contact your network administrator.

Range: Select a value from 0 to 63.

Example: Network 1 QoS Diffserv Audio: 0

Network [1..1] QoS Diffserv Data

The Diffserv Data defines which priority Data packets should have in an IP network. Enter a priority, which ranges from 0 to 63 for the packets. The higher the number, the higher the priority. These priorities might be overridden when packets are leaving the network controlled by the local network administrator. NOTE: Requires the Network QoS Mode to be set to Diffserv.

Requires user role: ADMIN

Value space: <0..63>

Data: A recommended value is Diffserv Code Point (DSCP) AF23, which equals the value 22. If in doubt, contact your network administrator.

Range: Select a value from 0 to 63.

Example: Network 1 QoS Diffserv Data: 0

Network [1..1] QoS Diffserv Signalling

The Diffserv Signalling defines which priority Signalling packets should have in an IP network. Enter a priority, which ranges from 0 to 63 for the packets. The higher the number, the higher the priority. These priorities might be overridden when packets are leaving the network controlled by the local network administrator. NOTE: Requires the Network QoS Mode to be set to Diffserv.

Requires user role: ADMIN

Value space: <0..63>

Signalling: A recommended value is Diffserv Code Point (DSCP) AF31, which equals the value 26. If in doubt, contact your network administrator.

Range: Select a value from 0 to 63.

Example: Network 1 QoS Diffserv Signalling: 0

Network [1..1] QoS Diffserv Video

The Diffserv Video defines which priority Video packets should have in an IP network. Enter a priority, which ranges from 0 to 63 for the packets. The higher the number, the higher the priority. These priorities might be overridden when packets are leaving the network controlled by the local network administrator. NOTE: Requires the Network QoS Mode to be set to Diffserv.

Requires user role: ADMIN

Value space: <0..63>

Video: A recommended value is Diffserv Code Point (DSCP) AF41, which equals the value 34. If in doubt, contact your network administrator.

Range: Select a value from 0 to 63.

Example: Network 1 QoS Diffserv Video: 0

Network [1..1] DNS Server [1..5] Address

Define the network addresses for DNS servers. Up to 5 addresses may be specified. If the network addresses are unknown, contact your administrator or Internet Service Provider.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Network 1 DNS Server 1 Address: ""

Network [1..1] DNS Domain Name

DNS Domain Name is the default domain name suffix which is added to unqualified names.

Example: If the DNS Domain Name is "company.com" and the name to lookup is "MyVideoSystem", this will result in the DNS lookup "MyVideoSystem.company.com".

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Network 1 DNS Domain Name: ""

Network [1..1] IEEE8021X Mode

The system can be connected to an IEEE 802.1X LAN network, with a port-based network access control that is used to provide authenticated network access for Ethernet networks.

Requires user role: ADMIN

Value space: <On/Off>

On: The 802.1X authentication is enabled.

Off: The 802.1X authentication is disabled (default).

Example: Network 1 IEEE8021X Mode: Off

Network [1..1] IEEE8021X AnonymousIdentity

The 802.1X Anonymous ID string is to be used as unencrypted identity with EAP (Extensible Authentication Protocol) types that support different tunneled identity, like EAP-PEAP and EAP-TTLS. If set, the anonymous ID will be used for the initial (unencrypted) EAP Identity Request.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Network 1 IEEE8021X AnonymousIdentity: ""

Network [1..1] IEEE8021X Identity

The 802.1X Identity is the user name needed for 802.1X authentication.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Network 1 IEEE8021X Identity: ""

Network [1..1] IEEE8021X Password

The 802.1X Password is the password needed for 802.1X authentication.

Requires user role: ADMIN

Value space: <S: 0, 32>

Format: String with a maximum of 32 characters.

Example: Network 1 IEEE8021X Password: "****"

Network [1..1] IEEE8021X Eap Md5

Set the Md5 (Message-Digest Algorithm 5) mode. This is a Challenge Handshake Authentication Protocol that relies on a shared secret. Md5 is a Weak security.

Requires user role: ADMIN

Value space: <On/Off>

On: The EAP-MD5 protocol is enabled (default).

Off: The EAP-MD5 protocol is disabled.

Example: Network 1 IEEE8021X Eap Md5: On

Network [1..1] IEEE8021X Eap Peap

Set the Peap (Protected Extensible Authentication Protocol) mode. Authenticates LAN clients without the need for client certificates. Developed by Microsoft, Cisco and RSA Security.

Requires user role: ADMIN

Value space: <On/Off>

On: The EAP-PEAP protocol is enabled (default).

Off: The EAP-PEAP protocol is disabled.

Example: Network 1 IEEE8021X Eap Peap: On

Network [1..1] IEEE8021X Eap TTLS

Set the TTLS (Tunneled Transport Layer Security) mode. Authenticates LAN clients without the need for client certificates. Developed by Funk Software and Certicom. Usually supported by Agere Systems, Proxim and Avaya.

Requires user role: ADMIN

Value space: <On/Off>

On: The EAP-TTLS protocol is enabled (default).

Off: The EAP-TTLS protocol is disabled.

Example: Network 1 IEEE8021X Eap TTLS: On

Network [1..1] TrafficControl Mode

Set the network traffic control mode to decide how to control the the video packets transmission speed.

Requires user role: ADMIN

Value space: <On/Off>

On: Transmit video packets at maximum 20Mbps. Can be used to smooth out bursts in the outgoing network traffic.

Off: Transmit video packets at link speed.

Example: Network 1 TrafficControl: On

Network [1..1] RemoteAccess Allow

Filter IP addresses for access to ssh/telnet/HTTP/HTTPS.

Requires user role: ADMIN

Value space: <S: 0, 255>

Format: String with a maximum of 255 characters, comma separated IP addresses or IP range.

Example: Network 1 RemoteAccess Allow: "192.168.1.231, 192.168.1.182"

The NetworkServices settings

NetworkServices Multiway Address

The Multiway address must be equal to the Conference Factory Alias, as configured on the Video Communication Server. The Multiway™ conferencing enables video endpoint users to introduce a 3rd party into an existing call.

Multiway™ can be used in the following situations:

- 1) When you want to add someone else in to your existing call.
- 2) When you are called by a 3rd party while already in a call and you want to include that person in the call.

Requirements: Codec C60/C40 must be running TC4.0 (or later), Video Communication Server (VCS) version X5 (or later) and Codian MCU version 3.1 (or later). Endpoints invited to join the Multiway™ conference must support the H.323 routeToMC facility message if in an H.323 call, or SIP REFER message if in a SIP call.

Requires user role: ADMIN

Value space: <S: 0, 255>

Format: String with a maximum of 255 characters.

Example: NetworkServices Multiway Address: "h323:multiway@company.com"

NetworkServices Multiway Protocol

Determine the protocol to be used for Multiway calls. NOTE: Requires a restart of the codec.

Requires user role: ADMIN

Value space: <Auto/H323/SIP>

Auto: The system will select the protocol for Multiway calls.

H323: The H323 protocol will be used for Multiway calls.

SIP: The SIP protocol will be used for Multiway calls.

Example: NetworkServices Multiway Protocol: Auto

NetworkServices Telnet Mode

Telnet is a network protocol used on the Internet or Local Area Network (LAN) connections.

Requires user role: ADMIN

Value space: <On/Off>

On: The Telnet protocol is enabled.

Off: The Telnet protocol is disabled. This is the factory setting.

Example: NetworkServices Telnet Mode: Off

NetworkServices SSH Mode

SSH (or Secure Shell) protocol can provide secure encrypted communication between the codec and your local computer.

Requires user role: ADMIN

Value space: <On/Off>

On: The SSH protocol is enabled.

Off: The SSH protocol is disabled.

Example: NetworkServices SSH Mode: On

NetworkServices SSH AllowPublicKey

Secure Shell (SSH) public key authentication can be used to access the codec.

Requires user role: ADMIN

Value space: <On/Off>

On: The SSH public key is allowed.

Off: The SSH public key is not allowed.

Example: NetworkServices SSH AllowPublicKey: On

NetworkServices HTTP Mode

Set the HTTP mode to enable/disable access to the system through a web browser. The web interface is used for system management, call management such as call transfer, diagnostics and software uploads.

Requires user role: ADMIN

Value space: <On/Off>

On: The HTTP protocol is enabled.

Off: The HTTP protocol is disabled.

Example: NetworkServices HTTP Mode: On

NetworkServices HTTPS Mode

HTTPS is a web protocol that encrypts and decrypts user page requests as well as the pages that are returned by the web server.

Requires user role: ADMIN

Value space: <On/Off>

On: The HTTPS protocol is enabled.

Off: The HTTPS protocol is disabled.

Example: NetworkServices HTTPS Mode: On

NetworkServices HTTPS VerifyServerCertificate

When the system connects to an external HTTPS server (like a phonebook server or an external manager), this server will present a certificate to the system to identify itself.

Requires user role: ADMIN

Value space: <On/Off>

On: Requires the system to verify that the server certificate is signed by a trusted Certificate Authority (CA). This requires that list of trusted CA's are uploaded to the system in advance.

Off: Do not verify server certificates.

Example: NetworkServices HTTPS VerifyServerCertificate: Off

NetworkServices HTTPS VerifyClientCertificate

When the system connects to a HTTPS client (like a web browser), the client can be asked to present a certificate to the system to identify itself.

Requires user role: ADMIN

Value space: <On/Off>

On: Requires the client to present a certificate that is signed by a trusted Certificate Authority (CA). This requires that list of trusted CA's are uploaded to the system in advance.

Off: Do not verify client certificates.

Example: NetworkServices HTTPS VerifyClientCertificate: Off

NetworkServices SNMP Mode

SNMP (Simple Network Management Protocol) is used in network management systems to monitor network-attached devices (routers, servers, switches, projectors, etc) for conditions that warrant administrative attention. SNMP exposes management data in the form of variables on the managed systems, which describe the system configuration. These variables can then be queried (set to ReadOnly) and sometimes set (set to ReadWrite) by managing applications.

Requires user role: ADMIN

Value space: <Off/ReadOnly/ReadWrite>

Off: Disable the SNMP network service.

ReadOnly: Enable the SNMP network service for queries only.

ReadWrite: Enable the SNMP network service for both queries and commands.

Example: NetworkServices SNMP Mode: ReadWrite

NetworkServices SNMP CommunityName

Enter the name of the Network Services SNMP Community. SNMP Community names are used to authenticate SNMP requests. SNMP requests must have a password (case sensitive) in order to receive a response from the SNMP Agent in the codec. The default password is "public". If you have the Cisco TelePresence Management Suite (TMS) you must make sure the same SNMP Community is configured there too. NOTE: The SNMP Community password is case sensitive.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: NetworkServices SNMP CommunityName: "public"

NetworkServices SNMP SystemContact

Enter the name of the Network Services SNMP System Contact.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: NetworkServices SNMP SystemContact: ""

NetworkServices SNMP SystemLocation

Enter the name of the Network Services SNMP System Location.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: NetworkServices SNMP SystemLocation: ""

NetworkServices SNMP Host [1..3] Address

Enter the address of up to three SNMP Managers. All traps will then be sent to the hosts listed.

The system's SNMP Agent (in the codec) responds to requests from SNMP Managers (a PC program etc.). SNMP Traps are generated by the SNMP Agent to inform the SNMP Manager about important events. Can be used to send event created messages to the SNMP agent about different events like: system reboot, system dialling, system disconnecting, MCU call, packet loss etc. Traps can be sent to multiple SNMP Trap Hosts.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: NetworkServices SNMP Host 1 Address: ""

NetworkServices H323 Mode

Determine whether the system should be able to place and receive H.323 calls. NOTE: Requires a restart of the codec.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable the possibility to place and receive H.323 calls (default).

Off: Disable the possibility to place and receive H.323 calls.

Example: NetworkServices H323 Mode: On

NetworkServices SIP Mode

Determine whether the system should be able to place and receive SIP calls. NOTE: Requires a restart of the codec.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable the possibility to place and receive SIP calls (default).

Off: Disable the possibility to place and receive SIP calls.

Example: NetworkServices SIP Mode: On

NetworkServices NTP Mode

The Network Time Protocol (NTP) is used to synchronize the time of the system to a reference time server. The time server will subsequently be queried every 24th hour for time updates. The time will be displayed on the top of the screen. The system will use the time to timestamp messages transmitted to Gatekeepers or Border Controllers requiring H.235 authentication. The system will use the time to timestamp messages transmitted to Gatekeepers or Border Controllers that requires H.235 authentication. It is also used for timestamping Placed Calls, Missed Calls and Received Calls.

Requires user role: ADMIN

Value space: <Auto/Manual>

Auto: The system will use the NTP server, by which address is supplied from the DHCP server in the network. If no DHCP server is used, or the DHCP server does not provide the system with a NTP server address, the system will use the static defined NTP server address specified by the user.

Manual: The system will always use the static defined NTP server address specified by the user.

Example: NetworkServices NTP Mode: Manual

NetworkServices NTP Address

Enter the NTP Address to define the network time protocol server address. This address will be used if NTP Mode is set to Manual, or if set to Auto and no address is supplied by a DHCP server.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: NetworkServices NTP Address: "1.tandberg.pool.ntp.org"

The Phonebook settings

Phonebook Server [1..1] ID

Enter a name for the external phonebook.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Phonebook Server 1 ID: ""

Phonebook Server [1..1] Type

Select the phonebook server type.

Requires user role: ADMIN

Value space: <VCS/TMS/Callway>

VCS: Select VCS if the phonebook is located on the Cisco TelePresence Video Communication Server.

TMS: Select TMS if the phonebook is located on the Cisco TelePresence Management Suite server.

Callway: Select Callway if the phonebook is to be provided by the Callway subscription service. Contact your Callway provider for more information.

Example: Phonebook Server 1 Type: TMS

Phonebook Server [1..1] URL

Enter the address (URL) to the external phonebook server.

Requires user role: ADMIN

Value space: <S: 0, 255>

Format: String with a maximum of 255 characters.

Example: Phonebook Server 1 URL: "http://tms.company.com/tms/public/external/phonebook/phonebook.asmx"

The Provisioning settings

Provisioning Mode

Provides the possibility of managing the codec (endpoint) by using an external manager/management system.

Requires user role: ADMIN

Value space: <Off/TMS/VCS/Callway>

Off: The system will not try to register to any management system.

TMS: If set to TMS (Cisco TelePresence Management System) the system will try to register with a TMS server. Contact your Cisco representative for more information.

VCS: If set to VCS (Cisco TelePresence Video Communication Server) the system will try to register with a VCS. Contact your Cisco representative for more information.

Callway: If set to Callway the system will try to register with the Callway subscription provider. Contact your Callway provider for more information.

Example: Provisioning Mode: TMS

Provisioning LoginName

Enter the user id provided by the provisioning server. This is the user name part of the credentials used to authenticate towards the HTTP server when using HTTP provisioning.

Requires user role: ADMIN

Value space: <S: 0, 80>

Format: String with a maximum of 80 characters.

Example: Provisioning LoginName: ""

Provisioning Password

Enter the password provided by the provisioning server. This is the password part of the credentials used to authenticate towards the HTTP server when using HTTP provisioning.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Provisioning Password: ""

Provisioning HttpMethod

Select the HTTP method to be used for the provisioning.

Requires user role: ADMIN

Value space: <GET/POST>

GET: Select GET when the provisioning server supports GET.

POST: Select POST when the provisioning server supports POST.

Example: Provisioning HttpMethod: POST

Provisioning ExternalManager Address

Enter the IP Address to the External Manager/Management system. If an External Manager address and a path is configured, the system will post an HTTP message to this address when starting up. When receiving this HTTP posting the External Manager (typically a management system) can return configurations/commands to the unit as a result. If the DHCP Option 242 is returned in the DHCP response from the DHCP server the system will interpret this as the External Manager address to use.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: Only the valid IP address format is accepted. An IP address that contains letters (192.a.2.0) or invalid IP addresses (192.0.1234.0) will be rejected.

Example: Provisioning ExternalManager Address: ""

Provisioning ExternalManager Protocol

Determine whether or not to use secure management.

Requires user role: ADMIN

Value space: <HTTP/HTTPS>

HTTP: Set to HTTP to disable secure management. Requires HTTP to be enabled in the NetworkServices HTTP Mode setting.

HTTPS: Set to HTTPS to enable secure management. Requires HTTPS to be enabled in the NetworkServices HTTPS Mode setting.

Example: Provisioning ExternalManager Protocol: HTTP

Provisioning ExternalManager Path

Set the path to the External Manager/Management system. If an External Manager address and a path is configured, the system will post an HTTP message to this address when starting up. When receiving this HTTP posting the External Manager (typically a management system) can return configurations/commands to the unit as a result. If the DHCP Option 242 is returned in the DHCP response from the DHCP server the system will interpret this as the External Manager address to use.

Requires user role: ADMIN

Value space: <S: 0, 255>

Format: String with a maximum of 255 characters.

Example: Provisioning ExternalManager Path: "tms/public/external/management/SystemManagementService.asmx"

Provisioning ExternalManager Domain

Enter the SIP domain for the provisioning server.

Requires user role: ADMIN

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Provisioning ExternalManager Domain: "any.domain.com"

The Security settings

Security Audit Server Address

Enter the external/global IP-address to the audit syslog server.

Requires user role: AUDIT

Value space: <S: 0, 64>

Format: String with a maximum of 64 characters.

Example: Security Audit Server Address: ""

Security Audit Server Port

Enter the port of the syslog server that the system shall send its audit logs to. A user with AUDIT rights is required to change this setting.

Requires user role: AUDIT

Value space: <0..65535>

Range: Select a value from 0 to 65535.

Example: Security Audit Server Port: 514

Security Audit OnError Action

Describes what actions will be taken if connection to the syslog server is lost. A user with AUDIT rights is required to change this setting.

Requires user role: AUDIT

Value space: <Halt/Ignore>

Halt: If the connection to the syslog server is lost for more than a few seconds, the system will reboot and try to establish connection. If connection is restored, the audit logs are respooled to the syslog server, and the system starts up again.

Ignore: The system will continue its normal operation, and rotate internal logs when full. When connection is restored it will again sends its audit logs to the syslog server.

Example: Security Audit OnError Action: Ignore

Security Audit Logging Mode

Describes where the audit logs are recorded or transmitted. A user with AUDIT rights is required to change this setting.

Requires user role: AUDIT

Value space: <Off/Internal/External/ExternalSecure>

Off: No audit logging is performed.

Internal: The system records the audit logs to internal logs, and rotates logs when they are full.

External: The system sends the audit logs to an external audit server.

ExternalSecure: The system sends the audit logs to an external audit server that is verified by the Audit CA list.

Example: Security Audit Logging Mode: Off

Security Session InactivityTimeout

Determines how long the system will accept inactivity from the user before he is automatically logged out.

Requires user role: AUDIT

Value space: <0..10000>

Range: Select a value from 0 to 10000 seconds. 0 means the that inactivity will not enforce automatically logout.

Example: Security Session InactivityTimeout: 0

The SerialPort settings

SerialPort Mode

Set the COM 1 serial port to be enabled/disabled.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable the COM 1 serial port.

Off: Disable the COM 1 serial port.

Example: SerialPort Mode: On

SerialPort BaudRate

Specify the baud rate (data transmission rate, bits per second) for the COM port on the codec. The default value is 38400.

Connection parameters for the COM port: Data bits: 8; Parity: None; Stop bits: 1; Flow control: None.

Requires user role: ADMIN

Value space: <9600/19200/38400/57600/115200>

Range: Select a baud rate from the baud rates listed (bps).

Example: SerialPort BaudRate: 38400

SerialPort LoginRequired

Determine if login shall be required when connecting to the COM port at the codec.

Requires user role: ADMIN

Value space: <On/Off>

On: Login is required when connecting to the codec through COM port.

Off: The user can access the codec through COM port without any login.

Example: SerialPort LoginRequired: On

The SIP settings

SIP Profile [1..1] URI

The SIP URI or number is used to address the system. This is the URI that is registered and used by the SIP services to route inbound calls to the system. A Uniform Resource Identifier (URI) is a compact string of characters used to identify or name a resource.

Requires user role: ADMIN

Value space: <S: 0, 255>

Format: Compact string with a maximum of 255 characters.

Example: SIP Profile 1 URI: "sip:firstname.lastname@company.com"

SIP Profile [1..1] DefaultTransport

Select the transport protocol to be used over the LAN.

Requires user role: ADMIN

Value space: <UDP/TCP/TLS/Auto>

UDP: The system will always use UDP as the default transport method.

TCP: The system will always use TCP as the default transport method.

TLS: The system will always use TLS as the default transport method. For TLS connections a SIP CA-list can be uploaded using the web interface. If no such CA-list is available on the system then anonymous Diffie Hellman will be used.

Auto: The system will try to connect using transport protocols in the following order: TLS, TCP, UDP.

Example: SIP Profile 1 DefaultTransport: Auto

SIP Profile [1..1] TlsVerify

For TLS connections a SIP CA-list can be uploaded using the web interface.

Requires user role: ADMIN

Value space: <On/Off>

On: Set to On to verify TLS connections. Only TLS connections to servers, whom x.509 certificate is validated against the CA-list, will be allowed.

Off: Set to Off to allow TLS connections without verifying them. The TLS connections are allowed to be set up without verifying the x.509 certificate received from the server against the local CA-list. This should

typically be selected if no SIP CA-list has been uploaded.

Example: SIP Profile 1 TlsVerify: Off

SIP Profile [1..1] Type

Enables SIP extensions and special behaviour for a vendor or provider.

Requires user role: ADMIN

Value space: <Standard/Alcatel/Avaya/Cisco/Microsoft/Nortel/Experimental/Siemens>

Standard: Should be used when registering to standard SIP proxy like OpenSer.

Alcatel: Must be used when registering to a Alcatel-Lucent OmniPCX Enterprise R7 or later.

Avaya: Must be used when registering to a Avaya Communication Manager.

Cisco: Must be used when registering to a Cisco CallManager version 5 or later.

Microsoft: Must be used when registering to a Microsoft LCS or OCS server.

Nortel: Must be used when registering to a Nortel MCS 5100 or MCS 5200 PBX.

Experimental: Can be used if auto is not working. NOTE: This mode is for testing purposes only.

Example: SIP Profile 1 Type: Standard

SIP Profile [1..1] Outbound

The client initiated connections mechanism for firewall traversal, connection reuse and redundancy. The current version supports <http://tools.ietf.org/html/draft-ietf-sip-outbound-20>.

Requires user role: ADMIN

Value space: <On/Off>

On: Set up multiple outbound connections to servers in the Proxy Address list.

Off: Connect to the single proxy configured first in Proxy Address list.

Example: SIP Profile 1 Outbound: Off

SIP Profile [1..1] Proxy [1..4] Discovery

Select if the SIP Proxy address is to be obtained manually or by using Dynamic Host Configuration Protocol (DHCP).

Requires user role: ADMIN

Value space: <Auto/Manual>

Manual: When Manual is selected, the manually configured SIP Proxy address will be used.

Auto: When Auto is selected, the SIP Proxy address is obtained using Dynamic Host Configuration Protocol (DHCP).

Example: SIP Profile 1 Proxy 1 Discovery: Manual

SIP Profile [1..1] Proxy [1..4] Address

The Proxy Address is the manually configured address for the outbound proxy. It is possible to use a fully qualified domain name, or an IP address. The default port is 5060 for TCP and UDP but another one can be provided. If Outbound is enabled, multiple proxies can be addressed.

Requires user role: ADMIN

Value space: <S: 0, 255>

Format: Compact string with a maximum of 255 characters. An IP address that contains letters (192.a.2.0) or invalid IP addresses (192.0.1234.0) will be rejected.

Example: SIP Profile 1 Proxy 1 Address: ""

SIP Profile [1..1] Authentication [1..1] LoginName

This is the user name part of the credentials used to authenticate towards the SIP proxy.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: SIP Profile 1 Authentication 1 LoginName: ""

SIP Profile [1..1] Authentication [1..1] Password

This is the password part of the credentials used to authenticate towards the SIP proxy.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: SIP Profile 1 Authentication 1 Password:

The Standby settings

Standby Control

Determine whether the system should go into standby mode or not.

Requires user role: ADMIN

Value space: <On/Off>

On: Enter standby mode when the Standby Delay has timed out. NOTE: Requires the Standby Delay to be set to an appropriate value.

Off: The system will not enter standby mode.

Example: Standby Control: On

Standby Delay

Define how long (in minutes) the system shall be in idle mode before it goes into standby mode. NOTE: Requires the Standby Control to be enabled.

Requires user role: ADMIN

Value space: <1..480>

Range: Select a value from 1 to 480 minutes.

Example: Standby Delay: 10

Standby WakeupAction

Define the camera position when leaving standby mode.

Requires user role: ADMIN

Value space: <None/Preset1/Preset2/Preset3/Preset4/Preset5/Preset6/Preset7/Preset8/Preset9/Preset10/Preset11/Preset12/Preset13/Preset14/Preset15/RestoreCameraPosition/DefaultCameraPosition>

None: No action.

Preset1 to Preset15: When leaving standby the camera position will be set to the position defined by the selected preset.

RestoreCameraPosition: When leaving standby the camera position will be set to the position it had before entering standby.

DefaultCameraPosition: When leaving standby the camera position will be set to the factory default position.

Example: Standby WakeupAction: RestoreCameraPosition

Standby BootAction

Define the camera position after a restart of the codec.

Requires user role: ADMIN

Value space: <None/Preset1/Preset2/Preset3/Preset4/Preset5/Preset6/Preset7/Preset8/Preset9/Preset10/Preset11/Preset12/Preset13/Preset14/Preset15/RestoreCameraPosition/DefaultCameraPosition>

None: No action.

Preset1 to Preset15: After a reboot the camera position will be set to the position defined by the selected preset.

RestoreCameraPosition: After a reboot the camera position will be set to the position it had before the last boot.

DefaultCameraPosition: After a reboot the camera position will be set to the factory default position.

Example: Standby BootAction: DefaultCameraPosition

Standby StandbyAction

Define the camera position when going into standby mode.

Requires user role: ADMIN

Value space: <None/PrivacyPosition>

None: No action.

PrivacyPosition: Turns the camera to a sideways position for privacy.

Example: Standby StandbyAction: PrivacyPosition

The SystemUnit settings

SystemUnit Name

Enter a System Name to define a name of the system unit. If the H.323 Alias ID is configured on the system then this ID will be used instead of the system name. The system name will be displayed:

- 1) When the codec is acting as an SNMP Agent.
- 2) Towards a DHCP server.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: SystemUnit Name: "Meeting Room"

SystemUnit MenuLanguage

Select the language to be used in the menus on screen.

Requires user role: USER

Value space: <English/ChineseSimplified/ChineseTraditional/Danish/Dutch/Finnish/French/German/Italian/Japanese/Korean/Norwegian/Polish/PortugueseBrazilian/Russian/Spanish/SpanishLatinAmerican/Swedish/Turkish>

Example: SystemUnit MenuLanguage: English

SystemUnit IrSensor Mode

Both the Codec C Series and PrecisionHD camera have IR sensors, and only one of them needs to be enabled at the time. The IR sensor LED is located on the front of the codec and the camera and flickers when an IR signal is received from the remote control.

Requires user role: ADMIN

Value space: <On/Off/Auto>

On: Enable the IR sensor on the codec.

Off: Disable the IR sensor on the codec.

Auto: The system will automatically disable the IR sensor on the codec if the IR sensor at camera is enabled. Otherwise, the IR sensor on the codec will be enabled.

Example: SystemUnit IrSensor Mode: Auto

SystemUnit ContactInfo Type

Describes what parameter to put in the status field in the upper left corner on the screen display. The information can also be read with the command `xStatus SystemUnit ContactInfo`.

Requires user role: ADMIN

Value space: <Auto/None/IPv4/IPv6/H323Id/E164Alias/SipUri/SystemName>

Auto: Shows the address which another system can dial to reach this system, depending on the default call protocol and system registration.

None: Do not show any contact information.

IPv4: Shows the IPv4 address as the contact information.

IPv6: Shows the IPv6 address as the contact information.

H323Id: Shows the H323 ID as the contact information.

E164Alias: Shows the H323 E164 Alias as the contact information.

SipUri: Shows the SIP URI as the contact information.

SystemName: Shows the system name as the contact information.

Example: `SystemUnit ContactInfo Type: Auto`

SystemUnit CallLogging Mode

Set the call logging mode for calls that are received or placed by the system. The call logs may then be viewed via the web interface or using the `xHistory` command.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable logging.

Off: Disable logging.

Example: `SystemUnit CallLogging Mode: On`

The Time settings

Time Zone

Set the time zone where the system is located, using Windows time zone description format.

Requires user role: USER

Value space: <GMT-12:00 (International Date Line West)/GMT-11:00 (Midway Island, Samoa)/GMT-10:00 (Hawaii)/GMT-09:00 (Alaska)/GMT-08:00 (Pacific Time (US & Canada); Tijuana)/GMT-07:00 (Arizona)/GMT-07:00 (Mountain Time (US & Canada))/GMT-07:00 (Chihuahua, La Paz, Mazatlan)/GMT-06:00 (Central America)/GMT-06:00 (Saskatchewan)/GMT-06:00 (Guadalajara, Mexico City, Monterrey)/GMT-06:00 (Central Time (US & Canada))/GMT-05:00 (Indiana (East))/GMT-05:00 (Bogota, Lima, Quito)/GMT-05:00 (Eastern Time (US & Canada))/GMT-04:30 (Caracas)/GMT-04:00 (La Paz)/GMT-04:00 (Santiago)/GMT-04:00 (Atlantic Time (Canada))/GMT-03:30 (Newfoundland)/GMT-03:00 (Buenos Aires, Georgetown)/GMT-03:00 (Greenland)/GMT-03:00 (Brasilia)/GMT-02:00 (Mid-Atlantic)/GMT-01:00 (Cape Verde Is.)/GMT-01:00 (Azores)/GMT (Casablanca, Monrovia)/GMT (Coordinated Universal Time)/GMT (Greenwich Mean Time : Dublin, Edinburgh, Lisbon, London)/GMT+01:00 (West Central Africa)/GMT+01:00 (Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna)/GMT+01:00 (Brussels, Copenhagen, Madrid, Paris)/GMT+01:00 (Sarajevo, Skopje, Warsaw, Zagreb)/GMT+01:00 (Belgrade, Bratislava, Budapest, Ljubljana, Prague)/GMT+02:00 (Harare, Pretoria)/GMT+02:00 (Jerusalem)/GMT+02:00 (Athens, Istanbul, Minsk)/GMT+02:00 (Helsinki, Kyiv, Riga, Sofia, Tallinn, Vilnius)/GMT+02:00 (Cairo)/GMT+02:00 (Bucharest)/GMT+03:00 (Nairobi)/GMT+03:00 (Kuwait, Riyadh)/GMT+03:00 (Moscow, St. Petersburg, Volgograd)/GMT+03:00 (Baghdad)/GMT+03:30 (Tehran)/GMT+04:00 (Abu Dhabi, Muscat)/GMT+04:00 (Baku, Tbilisi, Yerevan)/GMT+04:30 (Kabul)/GMT+05:00 (Islamabad, Karachi, Tashkent)/GMT+05:00 (Ekaterinburg)/GMT+05:30 (Chennai, Kolkata, Mumbai, New Delhi)/GMT+05:45 (Kathmandu)/GMT+06:00 (Sri Jayawardenepura)/GMT+06:00 (Astana, Dhaka)/GMT+06:00 (Almaty, Novosibirsk)/GMT+06:30 (Rangoon)/GMT+07:00 (Bangkok, Hanoi, Jakarta)/GMT+07:00 (Krasnoyarsk)/GMT+08:00 (Perth)/GMT+08:00 (Taipei)/GMT+08:00 (Kuala Lumpur, Singapore)/GMT+08:00 (Beijing, Chongqing, Hong Kong, Urumqi)/GMT+08:00 (Irkutsk, Ulaan Bataar)/GMT+09:00 (Osaka, Sapporo, Tokyo)/GMT+09:00 (Seoul)/GMT+09:00 (Yakutsk)/GMT+09:30 (Darwin)/GMT+09:30 (Adelaide)/GMT+10:00 (Guam, Port Moresby)/GMT+10:00 (Brisbane)/GMT+10:00 (Vladivostok)/GMT+10:00 (Hobart)/GMT+10:00 (Canberra, Melbourne, Sydney)/GMT+11:00 (Magadan, Solomon Is., New Caledonia)/GMT+12:00 (Fiji, Kamchatka, Marshall Is.)/GMT+12:00 (Auckland, Wellington)/GMT+13:00 (Nuku alofa)>

Range: Select a time zone from the list time zones. If using a command line interface; watch up for typos.

Example: `Time Zone: "GMT (Greenwich Mean Time : Dublin, Edinburgh, Lisbon, London)"`

Time TimeFormat

Set the time format.

Requires user role: USER

Value space: <24H/12H>

24H: Set the time format to 24 hours.

12H: Set the time format to 12 hours (AM/PM).

Example: Time TimeFormat: 24H

Time DateFormat

Set the date format.

Requires user role: USER

Value space: <DD _ MM _ YY/MM _ DD _ YY/YY _ MM _ DD>

DD_MM_YY: The date January 30th 2010 will be displayed: 30.01.10

MM_DD_YY: The date January 30th 2010 will be displayed: 01.30.10

YY_MM_DD: The date January 30th 2010 will be displayed: 10.01.30

Example: Time DateFormat: DD _ MM _ YY

The Video settings

Video AllowWebSnapshots

Allows web snapshots to be taken from the web interface.

NOTE: This is a local setting which is available only from the On Screen Display (OSD) and when connected directly to the serial port (COM port) on the codec.

Requires user role: ADMIN

Value space: <On/Off>

On: If set to on, a web snapshot can be generated and displayed on the web page under "Snapshot".

Off: The generation of web snapshots is not allowed.

Example: Video AllowWebSnapshots: Off

Video SelfviewPosition

Select where the small selfview PiP (Picture-in-Picture) will appear on screen.

Requires user role: ADMIN

Value space: <UpperLeft/UpperRight/LowerLeft/LowerRight/CenterRight>

UpperLeft: The selfview PiP will appear in the upper left corner of the screen.

UpperRight: The selfview PiP will appear in the upper right corner of the screen.

LowerLeft: The selfview PiP will appear in the lower left corner of the screen.

LowerRight: The selfview PiP will appear in the lower right corner of the screen.

CenterRight: The selfview PiP will appear in to the right side of the screen, in center.

Example: Video SelfviewPosition: LowerRight

Video Selfview

Determine if the selfview picture shall be displayed on screen.

Requires user role: ADMIN

Value space: <On/Off>

On: Set to On when you want selfview to be displayed on screen.

Off: Set to Off when you do not want selfview to be displayed on screen.

Example: Video Selfview: On

Video WallPaper

Determine if a background picture shall be displayed on screen when idle.

Requires user role: USER

Value space: <None/Growing/Summersky/Custom>

None: No wallpaper will be displayed on screen.

Summersky, Growing: Select one of the predefined wallpapers to be displayed on screen.

Custom: Custom: The custom wallpaper must be uploaded to the codec from the web interface.

1) On the video system: Find the IP address of the codec. Open the menu on screen and go to Home > Settings > System information to find the IP Address.

2) On your computer: Open a web browser and enter the IP address of the codec. Select "Wallpaper" from the menu, browse for the file, and press the "Upload" button.

3) On the video system: Open the menu on screen and go to Home > Settings > Wallpaper > Custom. Give it a few seconds to display the new picture. If the picture does not show, toggle once between "None" and "Custom" wallpaper to make the change take effect.

Example: Video Wallpaper: Summersky

Video MainVideoSource

Define which video input source shall be used as the main video source. The video input source is configured with the "Video Input Source [1..2] Connector" setting.

Requires user role: USER

Value space: <1..2>

Range: Select the source to be used as the main video source.

Example: Video MainVideoSource: 1

Video DefaultPresentationSource

Define which video input source shall be used as the default presentation source (e.g. when you press the Presentation key on the remote control). The video input source is configured with the "Video Input Source [1..2] Connector" setting.

Requires user role: USER

Value space: <1..2>

Range: Select the video source to be used as the presentation source.

Example: Video DefaultPresentationSource: 2

Video Monitors

Set the monitor layout mode.

Requires user role: ADMIN

Value space: <Single/Dual/DualPresentationOnly>

Single: The same layout is shown on all monitors.

Dual: The layout is distributed on two monitors.

DualPresentationOnly: All participants in the call will be shown on the first monitor, while the presentation (if any) will be shown on the second monitor.

Example: Video Monitors: Single

Video Input Source [1..2] Name

Enter a name for the video input source 1 to 2.

Requires user role: ADMIN

Value space: <S: 0, 50>

Format: String with a maximum of 50 characters.

Example: Video Input Source 1 Name: ""

Video Input Source 1 Connector

Select which video input connector to be active on video input source 1.

Requires user role: ADMIN

Value space: <HDMI>

HDMI: Select HDMI when you want to use the HDMI as input source 1.

Example: Video Input Source 1 Connector: HDMI

Video Input Source 2 Connector

Select which video input connector to be active on video input source 2.

Requires user role: ADMIN

Value space: <DVI>

DVI: Select DVI-I when you want to use the DVI-I 2 as input source 2.

Example: Video Input Source 2 Connector: DVI

Video Input Source [1..2] Type

Set which type of input source is connected to the video input.

Requires user role: ADMIN

Value space: <camera/PC/DVD/document _ camera/other>

Camera: Select Camera when you have a camera connected to the selected video input.

PC: Select PC when you have a PC connected to the selected video input.

DVD: Select DVD when you have a DVD player connected to the selected video input.

Document_Camera: Select Document_Camera when you have a document camera connected to the selected video input.

Other: Select Other when other equipment is connected to the selected video input.

Example: Video Input Source 1 Type: Camera

Video Input Source [1..2] Quality

When encoding and transmitting video there will be a tradeoff between high resolution and high framerate. For some video sources it is more important to transmit high framerate than high resolution and vice versa. The Quality setting specifies whether to give priority to high frame rate or to high resolution for a given source.

Requires user role: ADMIN

Value space: <Motion/Sharpness>

Motion: Gives the highest possible framerate. Used when there is a need for higher frame rates, typically when a large number of participants are present or when there is a lot of motion in the picture.

Sharpness: Gives the highest possible resolution. Used when you want the highest quality of detailed images and graphics.

Example: Video Input Source 1 Quality: Motion

Video Input Source [1..2] CameraControl Mode

Set the camera control mode for the camera associated with the video source 1 to 2.

Requires user role: ADMIN

Value space: <On/Off>

On: Enable camera control.

Off: Disable camera control.

Example: Video Input Source 1 CameraControl Mode: On

Video Input Source [1..2] CameraControl CameraId

Select the ID of the camera. NOTE: Requires the Video Input Source CameraControl Mode to be enabled.

Requires user role: ADMIN

Value space: <1>

Set the ID of the camera.

Example: Video Input Source 1 CameraControl CameraId: 1

Video Input Source [1..2] OptimalDefinition Profile

Adjust how rapidly the system will increase the transmitted resolution when increasing the bandwidth. NOTE: Requires that the Video Input Source Quality is set to Motion.

Normal: Use this setting for normal to poorly lit environment. If the source is a camera with 1920x1080p60, the system will transmit 1920x720p60 at about 2.2Mb/sec and above with this setting set to normal.

Medium: Requires better than normal and consistent lighting and good quality video inputs. If the source is a camera with 1920x1080p60, the system will transmit 1920x720p60 at about 1.4Mb/sec and above with this setting set to medium.

High: Requires good lighting conditions for a good overall experience and good quality video inputs. If the source is a camera with 1920x1080p60, the system will transmit 1920x720p60 at about 1.1Mb/sec and above with this setting set to high.

Requires user role: ADMIN

Value space: <Normal/Medium/High>

Ref: Table 1 and Table 2.

Example: Video Input Source 1 OptimalDefinition Profile: Normal

Table 1: Optimal definition, for systems supporting 1080p					
	w288p30	w448p30	w576p30	720p30	1080p30
Normal	256 kbit/s	512 kbit/s	768 kbit/s	1152 kbit/s	2560 kbit/s
Medium	128 kbit/s	384 kbit/s	512 kbit/s	1152 kbit/s	1920 kbit/s
High	128 kbit/s	256 kbit/s	512 kbit/s	768 kbit/s	1472 kbit/s

Table 2: Optimal definition, for systems supporting 720p60					
	w144p60	w288p60	w448p60	w576p60	720p60
Normal	128 kbit/s	512 kbit/s	1152 kbit/s	1472 kbit/s	2240 kbit/s
Medium	128 kbit/s	384 kbit/s	768 kbit/s	1152 kbit/s	1920 kbit/s
High	128 kbit/s	256 kbit/s	512 kbit/s	768 kbit/s	1152 kbit/s

Video Input Source [1..2] OptimalDefinition Threshold60fps

For each video input, this setting tells the system the lowest resolution where it should transmit 60fps. So for all resolutions lower than this, the maximum transmitted framerate would be 30fps, while above this resolution 60fps would also be possible, if the available bandwidth is adequate.

Requires user role: ADMIN

Value space: <512 _ 288/768 _ 448/1024 _ 576/1280 _ 720/Never>

512_288: Set the threshold to 512x288.

768_448: Set the threshold to 768x448.

1024_576: Set the threshold to 1024x576.

1280_720: Set the threshold to 1280x720.

Never: Do not set a threshold for transmitting 60fps.

Example: Video Input Source 1 OptimalDefinition Threshold60fps: 1280 _ 720

Video Input DVI [2] Type

The official DVI standard supports both digital and analog signals. In most cases the default AutoDetect setting can detect whether the signal is analog RGB or digital. However, in some rare cases when DVI-I cables are used (these cables can carry both the analog and digital signals) the auto detection fails. This setting makes it possible to override the AutoDetect and select the correct DVI video input.

Requires user role: USER

Value space: <AutoDetect/Digital/AnalogRGB>

AutoDetect: Set to AutoDetect to automatically detect if the signal is analog RGB or digital.

Digital: Set to Digital to force the DVI video input to Digital when using DVI-I cables with both analog and digital pins and AutoDetect fails.

AnalogRGB: Set to AnalogRGB to force the DVI video input to AnalogRGB when using DVI-I cables with both analog and digital pins and AutoDetect fails.

Example: Video Input DVI 2 Type: AutoDetect

Video Output HDMI [1..2] Resolution

Select the preferred resolution for the monitor connected to the video output HDMI connector. This will force the resolution on the monitor.

Requires user role: ADMIN

Value space: <Auto/640 _ 480 _ 60/800 _ 600 _ 60/1024 _ 768 _ 60/1280 _ 1024 _ 60/1280 _ 720 _ 60/1920 _ 1080 _ 60/1280 _ 768 _ 60/1360 _ 768 _ 60/1366 _ 768 _ 60/1600 _ 1200 _ 60/1920 _ 1200 _ 60>

Auto: The system will automatically try to set the optimal resolution based on negotiation with the connected monitor.

Range: 640x480@60p, 800x600@60p, 1024x768@60p, 1280x1024@60p, 1280x720@60p, 1920x1080@60p, 1280x768@60p, 1360x768@60p, 1366x768@60p, 1600x1200@60p, 1920x1200@60p

Example: Video Output HDMI 1 Resolution: 1920 _ 1080 _ 60

Video Output HDMI [1..2] OverscanLevel

Some TVs or other monitors may not display the whole image sent out on the systems video output, but cuts the outer parts of the image. In this case this setting can be used to let the system not use the outer parts of video resolution. Both the video and the OSD menu will be scaled in this case.

Requires user role: ADMIN

Value space: <Medium/High/None>

Medium: The system will not use the outer 3% of the output resolution.

High: The system will not use the outer 6% of the output resolution

None: The system will use all of the output resolution.

Example: Video Output HDMI 1 OverscanLevel: None

Video Output HDMI [1..2] MonitorRole

The HDMI monitor role describes what video stream will be shown on the monitor connected to the video output HDMI connector. Applicable only if the "Video > Monitors" configuration is set to dual.

Requires user role: ADMIN

Value space: <First/Second/PresentationOnly>

First: Show main video stream.

Second: Show presentation video stream if active, or other participants.

PresentationOnly: Show presentation video stream if active, and nothing else.

Example: Video Output HDMI 1 MonitorRole: First

Video Layout Scaling

Define how the system shall adjust the aspect ratio for images or frames when there is a difference between the image and the frame it is to be placed in.

Requires user role: ADMIN

Value space: <On/Off>

On: Let the system automatically adjust aspect ratio.

Off: No adjustment of the aspect ratio.

Example: Video Layout Scaling: On

Video Layout ScaleToFrame

Define what to do if the aspect ratio of a video input source doesn't match the aspect ratio of the corresponding image frame in a composition. For example if you have a 4:3 input source (like XGA) to be displayed on a 16:9 output (like HD720).

Requires user role: ADMIN

Value space: <Manual/MaintainAspectRatio/StretchToFit>

Manual: If the difference in aspect ratio between the video input source and the target image frame is less than the ScaleToFrameThreshold configuration (in percent), the image is stretched to fit. If not, the system will maintain the original aspect ratio.

MaintainAspectRatio: Will maintain the aspect ratio of the input source, and fill in black in the rest of the frame (letter boxing or pillar boxing).

StretchToFit: Will stretch (horizontally or vertically) the input source to fit into the image frame. NOTE: The general limitation is that you cannot upscale in one direction and at the same time downscale in the other direction. In such situations the codec will apply letterboxing.

Example: Video Layout ScaleToFrame: MaintainAspectRatio

Video Layout ScaleToFrameThreshold

Only applicable if the ScaleToFrame configuration is set to manual. If the difference in aspect ratio between the video input source and the target image frame is less than the ScaleToFrameThreshold configuration (in percent), the image is stretched to fit. If not, the system will maintain the original aspect ratio.

Requires user role: ADMIN

Value space: <0..100>

Range: Select a value from 0 to 100 percent.

Example: Video Layout ScaleToFrameThreshold: 5

Video Layout LocalLayoutFamily

Select which video layout family to be used locally.

Requires user role: ADMIN

Value space: <Auto/FullScreen/Equal/PresentationSmallSpeaker/PresentationLargeSpeaker>

Auto: The default layout family, as given by the layout database, will be used as the local layout. For more information about the layout database, see the command: xCommand Video Layout LoadDb.

FullScreen: The FullScreen layout family will be used as the local layout.

Equal: The Equal layout family will be used as the local layout.

PresentationSmallSpeaker: The PresentationSmallSpeaker layout family will be used as the local layout.

PresentationLargeSpeaker: The PresentationLargeSpeaker layout family will be used as the local layout.

Example: Video Layout LocalLayoutFamily: Auto

Video Layout RemoteLayoutFamily

Select which video layout family to be used for the remote participants.

Requires user role: ADMIN

Value space: <Auto/FullScreen/Equal/PresentationSmallSpeaker/PresentationLargeSpeaker>

Auto: The default layout family, as given by the local layout database, will be used as the remote layout. For more information about the layout database, see the command: xCommand Video Layout LoadDb.

FullScreen: The FullScreen layout family will be used as the remote layout.

Equal: The Equal layout family will be used as the remote layout.

PresentationSmallSpeaker: The PresentationSmallSpeaker layout family will be used as the remote layout.

PresentationLargeSpeaker: The PresentationLargeSpeaker layout family will be used as the remote layout.

Example: Video Layout RemoteLayoutFamily: Auto

Video OSD Mode

The Video OSD (On Screen Display) Mode lets you define if information and icons should be displayed on screen.

Requires user role: ADMIN

Value space: <On/Off>

On: Show the on screen menus, icons and indicators.

Off: Hide the on screen menus, icons and indicators.

Example: Video OSD Mode: On

Video OSD TodaysBookings

This setting can be used to display the systems bookings for today on the main OSD menu. This requires that the system is bookable by an external booking system, like Cisco TelePresence Management Suite (TMS).

Requires user role: ADMIN

Value space: <On/Off>

On: Displays information about this systems bookings on screen.

Off: Do not display todays bookings.

Example: Video OSD TodaysBookings: Off

Video OSD MyContactsExpanded

Set how the local contacts will be displayed in the phone book dialog in the OSD (On Screen Display).

Requires user role: ADMIN

Value space: <On/Off>

On: The local contacts in the phone book will be shown in the top level of the phonebook dialog.

Off: The local contacts will be placed in a separate folder called MyContacts in the phonebook dialog.

Example: Video OSD MyContactsExpanded: Off

Video OSD Output

The Video OSD (On Screen Display) Output lets you define which monitor should display the on screen menus, information and icons. By default the OSD is sent to the monitor connected to the Video OSD Output 1. If you cannot see the OSD on screen, then you must re-configure the OSD Output. You can do this by entering a key sequence on the remote control, from the web interface, or by a command line interface.

Using the remote control: Press the Disconnect key followed by: * # * # 0 x # (where x is output 1 to 2).

Using the web interface: Open a web browser and enter the IP address of the codec. Open the Advanced Configuration menu and navigate to Video OSD Output and select the video output.

Using a command line interface: Open a command line interface and connect to the codec (if in doubt of how to do this, see the API Guide for the codec). Enter the command: xConfiguration Video OSD Output [1..2] (select the OSD Output)

Requires user role: ADMIN

Value space: <1..2>

Range: Select 1 for HDMI output, or select 2 for DVI-I output.

Example: Video OSD Output: 1

Video OSD LoginRequired

Determine if the system should require the user to login before accessing the On Screen Display (OSD). If enabled, the user must enter his username and his PIN. After the user has logged in he can only execute to the configurations changes and commands allowed by his Role.

Requires user role: ADMIN

Value space: <On/Off>

On: The user must log in to access the On Screen Display (OSD).

Off: No login to the OSD is required.

Example: Video OSD LoginRequired: Off

Video OSD InputMethod InputLanguage

The codec can be enabled for Cyrillic input characters in the menus on screen. NOTE: Requires that Video OSD inputMethod Cyrillic is set to On.

Requires user role: ADMIN

Value space: <Latin/Cyrillic>

Latin: Latin characters can be entered when using the remote control (default).

Cyrillic: Cyrillic characters can be entered using the remote control. NOTE: Requires a Cisco TelePresence Remote Control with Cyrillic fonts.

Example: Video OSD InputMethod InputLanguage: Latin

Video OSD InputMethod Cyrillic

Set the Cyrillic mode for the menu input language in the menus on screen.

Requires user role: ADMIN

Value space: <On/Off>

On: Cyrillic mode is available as a menu input language in the menus on screen. This will enable the setting Video OSD InputMethod InputLanguage.

Off: Cyrillic mode is NOT available as a menu input language in the menus on screen.

Example: Video OSD InputMethod Cyrillic: Off

The Experimental settings

The Experimental settings are beta preview features and can be used 'as is'. They are not fully documented.

NOTE: The Experimental settings are likely to change without further notice.

Experimental CapsetFilter

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <S: 0, 100>

Example: Experimental CapsetFilter: ""

Experimental NetworkServices UPnP Mode

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <On/Off>

Example: Experimental NetworkServices UPnP Mode: Off

Experimental NetworkServices UPnP Timeout

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <0..3600>

Example: Experimental NetworkServices UPnP Timeout: 0

Experimental CustomSoftbuttons State [1..2] Softbutton [1..5] Type

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <NotSet/MainSource/PresentationSource/CameraPreset/Actions/SpeedDial>

Example: Experimental CustomSoftbuttons State 1 Softbutton 1 Type: NotSet

Experimental CustomSoftbuttons State [1..2] Softbutton [1..5] Value

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <S: 0, 255>

Example: Experimental CustomSoftbuttons State 1 Softbutton 1 Value: ""

Experimental Conference [1..1] PacketLossResilience ForwardErrorCorrection

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Will enable ForwardErrorCorrection (RFC5109) mechanism as part of the PacketLossResilience mechanism. Default value is On.

On: Forward error correction will be used as part of the PacketLossResilience mechanism.

Off: Forward error correction will NOT be used as part of the PacketLossResilience mechanism.

Requires user role: ADMIN

Value space: <On/Off>

Example: Experimental Conference 1 PacketLossResilience ForwardErrorCorrection: On

Experimental Conference [1..1] PacketLossResilience RateAdaption

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Will use the a RateAdaption algorithm adapted to the PacketLossResilience mechanism. Default value is On.

On: RateAdaption will be used as part of the PacketLossResilience mechanism.

Off: RateAdaption will NOT be used as part of the PacketLossResilience mechanism.

Requires user role: ADMIN

Value space: <On/Off>

Example: Experimental Conference 1 PacketLossResilience RateAdaption: On

Experimental SoftwareUpgrade Mode

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <Auto/Manual>

Example: Experimental SoftwareUpgrade Mode: Auto

Experimental SoftwareUpgrade ServerAddress

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <S: 0, 255>

Example: Experimental SoftwareUpgrade ServerAddress: "http://cupdate.tandberg.com/getswlist.py"

Experimental SystemUnit MenuType

NOTE: This Experimental command can be used 'as is' and will not be further documented. The Experimental settings WILL change.

Requires user role: ADMIN

Value space: <Indicators/Full>

Example: Experimental SystemUnit MenuType: Full

Chapter 4

Password protection

Password protection

The system is password protected in the following ways:

- The **Administrator settings menu** can be password protected with a menu password.
- The **Codec** is password protected. You always need to enter a username to log in.
The same username and password is used for the web and command line interfaces.
You can also configure the codec to prompt for a PIN-code before accessing all the on screen menus.
 - » The default username is **admin** with no password set.

NOTE: We recommend that you set a password for the **admin** user – see how to **Change your codec password** to the right.
 - » New user accounts with username and password/PIN-code can be created using the web interface.
Read more about user rights and how to add, edit and delete a user account in the ► **User management** section.
- You can protect the **File system** of the codec by setting a password for the **root** user. The root user is disabled by default.

NOTE: When a new administrator password has been defined make sure you keep a copy of the password in a safe place. Contact your Cisco representative if you have forgotten the password.

Set the Administrator settings menu password

When you set a password for the Administrator settings menu, all users must enter the password to get access to this menu, either on screen when using a remote control, or on the touch screen if you are using a Touch controller.

The menu password can be set from the on-screen menu, using a remote control or from a command line interface.

Set the menu password using the remote control

Perform the following steps to define a password for the Administrator settings menu:

1. In the on screen menu, go to **Home > Settings > Administrator settings > Set menu password**.
The password format is a string with 0–255 characters.
2. Enter the new password in the **Set password** menu.
3. Press **Save**.

Perform the following steps to change the password for the Administrator settings menu:

1. To change the password, go to **Home > Settings > Administrator settings > Set menu password**.
2. Enter the new password in the **Set password** menu.
3. Press **Save**.

Perform the following steps to deactivate the password for the Administrator settings menu:

1. To deactivate the password, go to **Home > Settings > Administrator settings > Set menu password**.
2. Leave the input field empty in the **Set password** menu.
3. Press **Save** to save the blank password. This will deactivate the Administrator settings menu password.

Set the menu password from a command line interface

Open a command line interface, for example PuTTY, and run the following command:

```
xCommand SystemUnit MenuPassword Set
Password: <password>
```

Change your codec password

A user, including the default **admin** user, can change his codec password using the web interface or the command line interface.

If a password is not currently set, use the procedure below with a blank current password.

Change the password using the web interface

Perform the following steps to change the codec password:

1. Log in to the web interface with your username and current password.
2. Go to the **Change password** page.
3. Enter the current password, the new password, and repeat the new password in the appropriate input fields.
The password format is a string with 0–255 characters.
4. Click **Save**.

Change the password using the command line interface

Perform the following steps to change the codec password:

1. Connect to the codec through the network or the serial data port, using a command line interface (SSH or Telnet).
2. Log in to the codec with your username and current password.
3. Run the following API command and when prompted enter the current password, the new password, and confirm the new password:
`systemtools passwd`
The password format is a string with 0–255 characters.

Change the user passwords

All users can change their own codec password as described on the previous page.

If you have ADMIN rights, you can change all users' passwords by performing the following steps:

1. Log in to the web interface with username and password.
2. Go to the **Users** page.
3. Select the appropriate user from the list.
4. Enter a new password and PIN code.
5. Click **Save**.

Set a root password

If you log in to the command line interface as `root`, you can access the codec's file system.

The root user is disabled by default.

Perform the following steps to activate the root user and set a password:

1. Connect to the codec through the network or the serial data port, using a command line interface (SSH or Telnet).
2. Log in to the codec with the username (`admin`) and password. You need ADMIN rights.
3. Run the following API command:

```
systemtools rootsettings on <password>
```

NOTE: The root password is not the same as the administrator password.

Chapter 5

Appendices

Connecting the Cisco TelePresence Touch controller to Codec C20

A C Series codec running software version TC4.1 or later can be controlled using the Cisco TelePresence Touch controller (instead of using the remote control).

Connect and set up the Touch controller

The Touch controller must be connected to Codec C20 via LAN.

Once the unit is connected to power, the set-up procedure begins. Follow the instructions on screen.

You have to select which codec to associate the Touch controller with. This process is called pairing.

NOTE: The codec signals that it is available for pairing only for 30 minutes after it is switched on.

If your codec is not in the list of available codecs displayed on the Touch controller, you can select a codec manually by entering its IP address.

If the Touch controller needs software upgrade, new software will be downloaded from the codec and installed on the unit automatically as part of the set-up procedure. The Touch controller restarts after the upgrade.

You can verify that the Touch controller is successfully paired to your codec by checking that the codec address is displayed in the top banner.

If you want more details on Touch installation, please read the *Cisco TelePresence Touch for C Series Installation Guide*, which you will find on the Cisco web site.



About monitors when you have a Codec C20

Connecting the monitor

The monitor can be connected to video output HDMI 1 (default) or HDMI 2*. The default resolution for HDMI is 1280x720@60Hz.

Connecting to HDMI 1

When connecting the monitor to HDMI 1, which is the default video output on Codec C20, the menu, icons and other information on screen (OSD - on screen display) will be displayed on this monitor.

Connecting to HDMI 2

When connecting the monitor to HDMI 2* output on Codec C20 the menus and icons is not automatically displayed on screen. The OSD must be moved to this output by running a key sequence on the remote control.

NOTE: There is no audio on HDMI 2.

Moving the OSD using the remote control

When connecting the main monitor to the HDMI 2 output, you must move the OSD to this output. If you cannot see any menu on screen you must run a key sequence on the remote control. The menu on screen, icons and other information (OSD - on screen display) will be moved to the selected output.

Check which connector the monitor is connected to, and run the following key sequence on the remote control.

- Disconnect * # * # 0 x # x=1 (HDMI 1) x=2 (HDMI 2)

Example 1: Set HDMI 1 as the OSD output:

- * - # - * - # - 0 - 1 - #

Example 2: Set HDMI 2 as the OSD output:

- * - # - * - # - 0 - 2 - #

* Use of HDMI 2 requires the Dual Display option.

The video outputs at Codec C20



Moving the OSD using the web interface

Go to the Advanced Configuration page and navigate to **Video > OSD > Output** and select the video output connector for the main monitor.

Dual monitors

NOTE: Requires the Dual Display option.

When you want to run a dual monitor setup, connect the main monitor to video output HDMI 1 and the second monitor to video output HDMI 2 on Codec C20.

Dual monitor configuration

Go to Advanced configuration (menu on screen or web interface) to set the monitor to dual:

1. Navigate to **Video > Output > Monitor** and set the Monitor to Dual.

Optimal definition profiles

Under ideal lighting conditions the bandwidth requirements can be substantially reduced with the optimal definitions profiles.

Generally, we recommend the Optimal Definition set at Normal.

If lighting conditions are good we recommend that you test the endpoint on the various Optimal Definition settings before deciding on a profile.

Go to Advanced configuration (menu on screen or web interface) to set the optimal definition profile:

- Navigate to **Video > Input > Source [1..n] > OptimalDefinition > Profile** and select a profile.

You can set a resolution threshold below which the maximum frame rate will be 30 fps.

Go to Advanced configuration (menu on screen or web interface) to set the threshold:

- Navigate to **Video > Input > Source [1..n] > OptimalDefinition > Threshold60fps** and select a threshold.

The video input quality settings must be set to Motion to ensure the Optimal Definition to work. With the video input quality set to Sharpness, the endpoint will transmit the highest resolution possible, regardless of frame rate.

Go to Advanced configuration (menu on screen or web interface) to set the input quality:

- Navigate to **Video > Input > Source [1..n] > Quality** and set the video quality parameter.

You can read more about the video settings in the Advanced configuration settings chapter. Go to: [Advanced configuration](#)



High (720p60)

Typically used in dedicated video conferencing rooms. Requires good lighting conditions for a good overall experience.

Under ideal conditions the bandwidth requirements can be reduced by up to 50%.



Medium (w576p60)

Typically used in rooms with better than normal, and consistent lighting.

The bandwidth requirements can be reduced by up to 25%.



Normal (w448p60)

This setting is typically used in office environments where the environment is normal to poorly lit.

Generally, we recommend the Optimal Definition set at Normal.

Optimal definition profiles for systems supporting 1080p					
	w288p30	w448p30	w576p30	720p30	1080p30
Normal	256 kbit/s	512 kbit/s	768 kbit/s	1152 kbit/s	2560 kbit/s
Medium	128 kbit/s	384 kbit/s	512 kbit/s	1152 kbit/s	1920 kbit/s
High	128 kbit/s	256 kbit/s	512 kbit/s	768 kbit/s	1472 kbit/s

Optimal definition profiles for systems supporting 720p60					
	w144p60	w288p60	w448p60	w576p60	720p60
Normal	128 kbit/s	512 kbit/s	1152 kbit/s	1472 kbit/s	2240 kbit/s
Medium	128 kbit/s	384 kbit/s	768 kbit/s	1152 kbit/s	1920 kbit/s
High	128 kbit/s	256 kbit/s	512 kbit/s	768 kbit/s	1152 kbit/s

ClearPath – Packet loss resilience

ClearPath introduces advanced packet loss resilience mechanisms that increase the experienced quality when you use your video system in an error prone environment.

We recommend that you enable ClearPath on your video system.

Go to **Advanced configuration** (menu on screen or web interface) to switch on ClearPath:

- Navigate to **Conference 1 > PacketLossResilience > Mode** and select **On**.

Requirement for speaker systems connected to a Cisco TelePresence C Series codec

Cisco has put in a lot of effort to minimize the camera to screen delay on our TelePresence endpoints.

New consumer TVs are usually equipped with “Motion Flow” or similar technology to insert new video frames between standard frames to create smoother images. This processing takes time and to maintain lip synchronization, the TV will delay the audio so that the audio and video arrives at the same time.

The echo canceller in the Cisco endpoints can handle such delay up to 30ms. Many consumer TVs are not made for real time video communication and may introduce more than 30ms of delay.

If you use such a TV together with a C Series codec it is recommended that you turn off “Motion Flow”, “Natural Motion” or any other video processing that introduces additional delay.

Some consumer TVs also support advanced audio processing like “Virtual Surround” effects and “Dynamic Compression” to improve the TV experience. Such processing will make any acoustic echo canceller malfunction and should hence be switched off.


Some monitors are equipped with a setting called ‘Game Mode’. This mode is specifically designed to help reduce the response time and will usually help to reduce the delay.

Codec C20 – The physical interface

The front panel LEDs

The LED in front of the codec indicates the status of the codec.

- When the LED is **off** the codec is Off.
- The LED flashes **green** during the boot up and shut down of the codec.
- The LED pulses **green** when the infrared (IR) port is activated. This will occur when the remote control is in use.
- The LED is steady **green** when the codec is On, in Standby mode or in Presentation mode.
- When the LED is **red** this indicates an Error has occurred.



Codec C20 – The physical interface, continued...

The rear panel

The Quick Set C20/C20 Plus physical interface is described in this guide.

The connectors used in a basic setup are highlighted in **bold**.



Microphone 1-2

Mini-Jack 3.5 mm, 4-pole connector. Connect the microphone to Mic 1, which is the main connector.

Audio input

RCA sockets, mixed to mono. Used when connecting to PC and external playback devices, such as VCR's or DVD players.

Audio output

RCA sockets, mono. Used when connecting to a local loudspeaker system.

Network connector

Ethernet interface, 1 × 10Mb/100Mb/1 Gigabit Ethernet LAN (RJ-45 Jack) interface.

USB

For future use.

Camera Control port

Camera Control (RS-232) port for power and camera control (pan, tilt, zoom) using the VISCA™* protocol. The Pin No. 4 on the Camera Control port provides 12 V DC / 1 A to the main camera.

DVI-I input for PC

DVI-I socket, digital/analog video input for PC presentations.

HDMI input for camera

HDMI socket, digital video input for camera.

HDMI output for the main monitor

HDMI socket, digital video and audio output for the main monitor.

HDMI output for the second monitor

HDMI socket, digital video output for the second monitor.

Power socket

The power socket accepts +12 V / 5 A (max) from the external adapter.

The external adapter accepts 100/240 V 50/60Hz and the maximal load is 75W.

Power switch

The power switch (push button) is located on the rear side.

- Push the button to boot up the codec.
- Push and hold the button for 1 second to shut down the codec.
- Push and hold the button for 7 seconds to force a shut down of the codec.

Kensington lock

The Kensington lock may be used to prevent the codec to be moved from its place or to prevent theft.

*VISCA™ is a trademark of Sony Corporation

Pin-out schemes

This page gives an overview of the pin-out schemes for C20.

HDMI pin-out
External view of socket

DVI-I pin-out
External view of socket

RS232 9 pin D-SUB pin-out
External view of socket

Microphone, 3.5 mm Mini-Jack, 4 pole

RCA pin-out
External view of socket

RJ-45 Connector pin-out

Wiring diagram standard cable

- 1 ----- 1
- 2 ----- 2
- 3 ----- 3
- 6 ----- 6

HDMI Pin-out			
Pin	Assignment	Pin	Assignment
1	T.M.D.S. Data 2+	11	T.M.D.S. Clock Shield
2	T.M.D.S. Data 2 Shield	12	T.M.D.S. Clock-
3	T.M.D.S. Data 2-	13	CEC
4	T.M.D.S. Data 1	14	Reserved (N.C. on device)
5	T.M.D.S. Data 1 Shield	15	SCL
6	T.M.D.S. Data 1-	16	SDA
7	T.M.D.S. Data 0	17	DDC/CEC Ground
8	T.M.D.S. Data 0 Shield	18	+5 V Power (max 50 mA)
9	T.M.D.S. Data 0-	19	Hot Plug Detect
10	T.M.D.S. Clock+		

Codec C20 audio connectors			
Connector pin out	Jack Mic input	RCA line input	RCA line output
Connector pin out	Tip = Hot Ring 1 = Cold Ring 2 = Mic. control Shield = GND	Pin = Signal Shield = GND	Pin = Signal Shield = GND
Signal type	Balanced	Unbalanced	Unbalanced
Connector (codec)	Mini Jack 3.5mm	Female RCA/ phono	Female RCA/ phono
Input impedance	1.5kOhm/leg	18k Ohm	
Output impedance			100 Ohm
Maximum input level	-18.3dBu +/-2dB	9.0dBu +/-2dB	
Maximum output level			8.2dBu +/-2dB
Phantom power	12V +/-1V		
Phantom power resistor pin "tip"	1.7kOhm		
Phantom power resistor pin "ring 1"	1.7kOhm		
Frequency response	20Hz-20kHz +/-1dB	20Hz-20kHz +/-1dB	20Hz-20kHz +/-1dB
Signal to Noise Ratio	-85dB	-95dB	-95dB

Pin-out-VISCA™ camera control RJ11, 8 pins shielded modular jack	
Pin	Signal name
8	+12V (presence 2.8mA current source when connected in daisy chain)
7	GND
6	TXD (out)
5	NC (no connect)
4	NC (no connect)
3	RXD (in)
2	GND
1	+12V


Pin-out-Camera cable			
Signal name	RJ-45 pin		D-SUB pin
+12V DC	1	Twisted pair	4
GND	2		5
RX	3	Twisted pair	2
TX	6		3
NC	4	Twisted pair	1
NC	5		6
GND	7	Twisted pair	5
+12V DC	8		4

Quick Set C20 – Cable configuration

The illustration shows you the basic setup when connecting the monitor, PC, **PrecisionHD 1080p 4X camera**, microphone, loudspeakers (if applicable), LAN and line voltage to the Codec C20.

NOTE: The early shipments of the Quick Set C20 came with an interim version of the PrecisionHD 1080p 4X camera (the PrecisionHD 1080p 4X* camera). For cable configurations of the interim PrecisionHD 1080p 4X* camera, see next page.

CAUTION: In order to be able to use the system for video calls, all orange colored sockets must be connected.




The codec must be switched off and disconnected from the line voltage whenever connecting or disconnecting other equipment.

Quick Set C20 Plus – Cable configuration

The illustration shows you the basic setup when connecting the monitor, PC, PrecisionHD 1080p 12X camera, microphone, loudspeakers (if applicable), LAN and line voltage to the Codec C20.

CAUTION: In order to be able to use the system for video calls, all orange colored sockets must be connected.



The codec must be switched off and disconnected from the line voltage whenever connecting or disconnecting other equipment.

DNAM for Profile 42”

The DNAM – Digital Natural Audio Module – is built on two specially designed and separate modules, the amplifier and the loudspeaker cabinet.


The DNAM Loudspeaker

- 3-way Center Loudspeaker system.
- Frequency range 50Hz - 20kHz.
- 2 x 100 mm low- and midrange loudspeaker 8 Ohms nominal, excellent quality (SEAS Prestige series).
- 1 x 25 mm dome tweeter, 6 ohms nominal, excellent quality.
- Active crossover filtered audio signals received from DNAM amplifier.
- Long time max power 70Watt on all loudspeakers.
- Enclosed MDF loudspeaker cabinet.

Integrated Left / Right Stereo Loudspeaker

Stereo Loudspeaker System, each side has:

- 1 x 90mm fullrange loudspeaker, 8 ohms nominal, excellent quality.
- Frequency range 70Hz - 20kHz.
- Enclosed MDF Loudspeaker cabinet.



The DNAM Amplifier

- 3 x 50W continuous average Center Output Power (load specified by DNAM Center Loudspeakers).
- 2 x 50W continuous average Stereo Output Power (load specified by DNAM Stereo Loudspeakers).
- Full dynamic range for audio (20Hz-20kHz).
- Digital Signal Processing and Filtering on all channels for best audio detail clarity.
- Digital Crossover Filtering on center channels.
- In/out:
 - Audio In - SPDIF (stereo) or Analog (mono), using the same connector.
 - Audio Differential In - (female XLR pinout: 1 - GND, 2 - Signal (+), 3 - Signal (-)).
 - Audio Loop Out - line out directly from the input, always analog even with SPDIF in.
 - Audio Stereo Out - (male XLR, common GND configuration).
- Fuse 2A 250V Slow, 5 x 20mm, Littelfuse type 215002. Push and twist counter-clockwise to release.

Technical specifications

Quick Set C20/C20 Plus

SET DELIVERED COMPLETE WITH:

Codec C20, PrecisionHD 1080p 4x or 12x camera, Precision MIC 20, remote control, cables and power supply

BANDWIDTH

H.323/SIP up to 6 Mbps point-to-point

FIREWALL TRAVERSAL

Cisco TelePresence ExpresswayTechnology
H.460.18, H.460.19 Firewall Traversal

VIDEO STANDARDS

H.261, H.263, H.263+, H.264

VIDEO FEATURES

Native 16:9 Widescreen
Advanced Screen Layouts
Intelligent Video Management
Local Auto Layout

VIDEO INPUTS (2 INPUTS)

1 x HDMI input, supported formats:

1920 x 1080@60 fps (1080p60)
1920 x 1080@50 fps (1080p50)
1920 x 1080@30 fps Hz (1080p30)
1920 x 1080@25 fps (1080p25)
1280 x 720@60 fps (720p60)
1280 x 720@50 fps (720p50)
640 x 480@60 fps (480p60)
800 x 600@60 fps (SVGA)
1024 x 768@60, 70, 75, 85 fps (XGA)
1280 x 1024@60, 75 fps (SXGA)

1 x DVI-I input, supported formats:

Analog (VGA):
1920 x 1080@60 Hz (1080p60)
1280 x 720@60 Hz (720p60)
1600 x 1200@60 Hz (UXGA)
1280 x 1024@60, 75 Hz (SXGA)

1280 x 960@60 Hz
1024 x 768@60, 70, 75, 85 Hz (XGA)
1920 x 1200@50 Hz (WUXGA)
1680 x 1050@60 Hz (WSXGA+)
1440 x 900@60 Hz (WXGA+)
1280 x 800@60 Hz (WXGA)
1280 x 768@60 Hz (WXGA)

Digital (DVI-D):
Same as HDMI, ref. above.

Extended Display Identification Data (EDID)

VIDEO OUTPUTS (2 OUTPUTS)

2 x HDMI output, supported formats:

1920 x 1080@60 fps (1080p60)
1280 x 720@60 fps (720p60)
1366 x 768@60 fps (WXGA)
1280 x 768@60 fps (WXGA)
1280 x 1024@60 fps (SXGA)
1024 x 768@60 fps (XGA)
800 x 600@60 fps (SVGA)
640 x 480@60 fps (VGA)

VESA Monitor Power Management
Extended Display Identification Data (EDID)

LIVE VIDEO RESOLUTIONS (ENCODE/DECODE)

176 x 144@30, 60 fps (QCIF)
352 x 288@30, 60 fps (CIF)
512 x 288@30, 60 fps (w288p)
576 x 448@30, 60 fps (448p)
768 x 448@30, 60 fps (w448p)
704 x 576@30, 60 fps (4CIF)
1024 x 576@30, 60 fps (w576p)
640 x 480@30, 60 fps (VGA)
800 x 600@30, 60 fps (SVGA)
1024 x 768@30 fps (XGA)
1280 x 768@30 fps (WXGA)
1280 x 720@30, 60* fps (720p30/60)
1920 x 1080@30 fps (1080p30)*

720p30 from 768kbps
720p60 from 1152kbps*
1080p30 from 1472 kbps*

AUDIO STANDARDS

G.711, G.722, G.722.1, 64 kbps MPEG4 AAC-LD

AUDIO FEATURES

CD-Quality 20KHz Mono
1 x Acoustic echo canceller
Automatic Gain Control (AGC)
Automatic Noise Reduction
Active lip synchronization

AUDIO INPUTS (4 INPUTS)

2 x Microphone, 4 pin MiniJack
2 x RCA/Phono (mixed to mono)

AUDIO OUTPUTS (3 OUTPUTS)

2 x RCA/Phono (dual mono)
1 x HDMI (digital main audio)

DUAL STREAM

H.239 (H.323) dual stream
BFCP (SIP) dual stream
Support resolutions up to WXGA (1280 x 768)
When Dual video stream is activated the main video stream maximum is 720p 30fps

PROTOCOLS

H.323
SIP

EMBEDDED ENCRYPTION

H.323/SIP point-to-point
Standards-based: H.235 v2 & v3 and AES
Automatic key generation and exchange
Supported in Dual Stream

IP NETWORK FEATURES

DNS lookup for service configuration
Differentiated Services (QoS)
IP adaptive bandwidth management (including flow control)
Auto gatekeeper discovery
Dynamic playout and lip-sync buffering
H.245 DTMF tones in H.323
Date and Time support via NTP
Packet Loss based Downspeeding
URI Dialing

TCP/IP

DHCP
802.1x Network authentication
ClearPath

IPv6 NETWORK SUPPORT

Single call stack support for both H323 and SIP
Dual-stack IPv4 and IPv6 for DHCP, SSH, HTTP, HTTPS, DNS, DiffServ
Support for both Static and Autoconfig (stateless address auto configuration)

SECURITY FEATURES

Management via HTTPS and SSH
IP Administration Password
Menu Administration Password
Disable IP services
Network Settings protection

NETWORK INTERFACES

1 x LAN/Ethernet (RJ-45) 10/100/1000 Mbit

OTHER INTERFACES

USB device for future usage

PRECISIONHD 1080P 12X CAMERA

1/3" CMOS
12 x zoom
+15°/-25° tilt, +/- 90° pan
43.5° vertical field of view
72° horizontal field of view
Focus distance 0.3m-infinity
1920 x 1080 pixels progressive @ 60fps
Other formats supported (configurable through Dip-switch):
1920 x 1080@60 Hz (HDMI only)
1920 x 1080@50 Hz (HDMI only)
1920 x 1080@30 Hz
1920 x 1080@25 Hz
1280 x 720@60 Hz
1280 x 720@50 Hz
1280 x 720@30 Hz
1280 x 720@25 Hz
Automatic or manual focus/brightness/white balance
Far-end camera control
Dual HDMI and HD-SDI output
Upside-down mounting with automatic flipping of picture

Quick Set C20/C20 Plus, continued...

PRECISIONHD 1080P 4X CAMERA

1/3" CMOS

4 x zoom

+15°/-25° tilt, +/- 90° pan

43.5° vertical field of view

72° horizontal field of view

Focus distance 0.3m-infinity

1920 x 1080 pixels progressive @ 30fps / 1280 x 720 pixels progressive @ 60fps

Automatic or manual focus/brightness/white balance

Far-end camera control

Upside-down mounting with manual flipping of picture

Note: The early shipments of the Quick Set C20 came with an interim version of the PrecisionHD 1080p 4X camera

SYSTEM MANAGEMENT

Support for the Cisco TelePresence Management Suite

Total management via embedded SNMP, Telnet, SSH, XML, SOAP

Remote software upload: via web server, SCP, HTTP, HTTPS

Remote control and on-screen menu system

DIRECTORY SERVICES

Support for Local directories (My Contacts)

Corporate Directory

Unlimited entries using Server directory supporting LDAP and H.350

Unlimited number for Corporate directory (through Cisco TelePresence Management Suite)

Received Calls with Date and Time

Placed Calls with Date and Time

Missed Calls with Date and Time

POWER

Auto-sensing power supply

100-120/200-240 VAC, 60/50 Hz

75 watts max. for codec and main camera

OPERATING TEMPERATURE AND HUMIDITY

0° C to 35° C (32° F to 95° F) ambient temperature

10% to 90% Relative Humidity (RH)

STORAGE AND TRANSPORT TEMPERATURE

-20° C to 60° C (-4° F to 140° F) at RH 10-90% (non-condensing)

DIMENSIONS

Codec C20:

Length: 13.8in/35.0cm

Height: 1.2in/3.0cm

Depth: 5in/12.7cm

Weight: 4lbs/1.8kg

APPROVALS

EU/EEC

Directive 2006/95/EC (Low Voltage Directive)

- Standard EN 60950-1

Camera Rev.03 (rating label):

EU/EEC

Directive 2004/108/EC (EMC Directive)

- Standard EN 55022, Class A

- Standard EN 55024

- Standard EN 61000-3-2/-3-3.

Warning: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

USA

Approved according to UL 60950-1

Complies with FCC15B Class A

Canada

Approved according to CAN/CSA-C22.2 No. 60950-1

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Camera Rev.04 (rating label):

EU/EEC

Directive 2004/108/EC (EMC Directive)

- Standard EN 55022, Class B

- Standard EN 55024

- Standard EN 61000-3-2/-3-3

USA

Approved according to UL 60950-1

Complies with FCC15B Class A

Canada

Approved according to CAN/CSA-C22.2 No. 60950-1

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

All specifications are subject to change without notice, system specifics may vary.

All images in these materials are for representational purposes only, actual products may differ.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company.

MTBF PRODUCT RELIABILITY/MTBF

The predicted reliability is expressed in the expected random Mean Time Between Failures (MTBF) for the electronic components based on the Power On Hours:

Power On Hours (POH) > 69 000 hours

Useful Life Cycle > 6 years

ISO 9001 certificate is available upon request

February 2011

* Requires option

Technical specifications

Profile 42” using C20

UNIT DELIVERED COMPLETE WITH:

Full HD LCD display, Codec C20, Touch screen UI, remote control, PrecisionHD Camera (1080p), Precision MIC 20 and choice of installation configuration: floor stand, wheel base or wall mount on pedestal.

MONITOR

Full HD LCD, 16:9, 1080x1920 resolution

BASE

Floor standing footplate
Wheel base
Wall mount on pedestal

PROTOCOLS

H.323
SIP

BANDWIDTH

H.323/SIP up to 6 Mbps point-to-point

VIDEO STANDARDS

H.261, H.263, H.263+, H.264

VIDEO FEATURES

Native 16:9 Widescreen
Advanced Screen Layouts
Intelligent Video Management
Local Auto Layout

DUAL STREAM

H.239 (H.323) dual stream
BFCP (SIP) dual stream
Support resolutions up to WXGA (1280 x 768)
When Dual video stream is activated the main video stream maximum is 720p 30fps

FIREWALL TRAVERSAL

Cisco TelePresence ExpresswayTechnology
H.460.18, H.460.19 Firewall Traversal

EMBEDDED ENCRYPTION

H.323/SIP point-to-point
Standards-based: H.235 v2 & v3 and AES
Automatic key generation and exchange
Supported in Dual Stream

IP NETWORK FEATURES

DNS lookup for service configuration
Differentiated Services (QoS)
IP adaptive bandwidth management (including flow control)
Auto gatekeeper discovery
Dynamic playout and lip-sync buffering
H.245 DTMF tones in H.323
Date and Time support via NTP
Packet Loss based Downsampling
URI Dialing
TCP/IP
DHCP
802.1x Network authentication
ClearPath

IPV6 NETWORK SUPPORT

Single call stack support for both H323 and SIP
Dual-stack IPv4 and IPv6 for DHCP, SSH, HTTP, HTTPS, DNS, DiffServ
Support for both Static and Autoconfig (stateless address auto configuration)

SECURITY FEATURES

Management via HTTPS and SSH
IP Administration Password
Menu Administration Password
Disable IP services
Network Settings protection

NETWORK INTERFACES

1 x LAN/Ethernet (RJ-45) 10/100/1000 Mbit

OTHER INTERFACES

USB device for future usage

PRECISIONHD 1080P 12X CAMERA

1/3" CMOS
12 x zoom
+15°/-25° tilt, +/- 90° pan
43.5° vertical field of view
72° horizontal field of view
Focus distance 0.3m-infinity
1920 x 1080 pixels progressive @ 60fps
Other formats supported (configurable through Dip-switch):
1920 x 1080@60 Hz (HDMI only)
1920 x 1080@50 Hz (HDMI only)
1920 x 1080@30 Hz
1920 x 1080@25 Hz
1280 x 720@60 Hz
1280 x 720@50 Hz
1280 x 720@30 Hz
1280 x 720@25 Hz

Automatic or manual focus/brightness/white balance
Far-end camera control
Dual HDMI and HD-SDI output
Upside-down mounting with automatic flipping of picture

SYSTEM MANAGEMENT

Support for the Cisco TelePresence Management Suite
Total management via embedded SNMP, Telnet, SSH, XML, SOAP
Remote software upload: via web server, SCP, HTTP, HTTPS
Remote control and on-screen menu system
Cisco TelePresence touch screen – touch user interface device

DIRECTORY SERVICES

Support for Local directories (My Contacts)
Corporate Directory
Unlimited entries using Server directory supporting LDAP and H.350
Unlimited number for Corporate directory (through Cisco TelePresence Management Suite)
Received Calls with Date and Time
Placed Calls with Date and Time
Missed Calls with Date and Time

POWER

Auto-sensing power supply
100-120/200-240 VAC, 60/50 Hz, 6 A max
75 watts maximum for codec and main camera
Maximum power rating (complete system) 265 W

OPERATING TEMPERATURE AND HUMIDITY

0° C to 35° C (32° F to 95° F) ambient temperature
10% to 90% Relative Humidity (RH)

STORAGE AND TRANSPORT TEMPERATURE

-20° C to 60° C (-4° F to 140° F) at RH 10-90% (non-condensing)

DIMENSIONS

Height: 63.78" / 162 cm
Width: 38.58" / 98 cm
Depth: 6.7" / 17 cm
Weight: 202.8 lbs / 92 kg

VIDEO INPUTS (2 INPUTS)

1 x HDMI input, supported formats:

1920 x 1080@60 fps (1080p60)
1920 x 1080@50 fps (1080p50)
1920 x 1080@30 fps Hz (1080p30)
1920 x 1080@25 fps (1080p25)
1280 x 720@60 fps (720p60)
1280 x 720@50 fps (720p50)
640 x 480@60 fps (480p60)
800 x 600@60 fps (SVGA)
1024 x 768@60, 70, 75, 85 fps (XGA)
1280 x 1024@60, 75 fps (SXGA)

1 x DVI-I input, supported formats:

Analog (VGA):
1920 x 1080@60 Hz (1080p60)
1280 x 720@60 Hz (720p60)
1600 x 1200@60 Hz (UXGA)
1280 x 1024@60, 75 Hz (SXGA)
1280 x 960@60 Hz
1024 x 768@60, 70, 75, 85 Hz (XGA)
1920 x 1200@50 Hz (WUXGA)
1680 x 1050@60 Hz (WSXGA+)
1440 x 900@60 Hz (WXGA+)
1280 x 800@60 Hz (WXGA)
1280 x 768@60 Hz (WXGA)

Profile 42” using C20, continued...

Digital (DVI-D):

Same as HDMI, ref. above.

Extended Display Identification Data (EDID)

VIDEO OUTPUTS (2 OUTPUTS)

2 x HDMI output, supported formats:

- 1920 x 1080@60 fps (1080p60)
- 1280 x 720@60 fps (720p60)
- 1366 x 768@60 fps (WXGA)
- 1280 x 768@60 fps (WXGA)
- 1280 x 1024@60 fps (SXGA)
- 1024 x 768@60 fps (XGA)
- 800 x 600@60 fps (SVGA)
- 640 x 480@60 fps (VGA)

VESA Monitor Power Management

Extended Display Identification Data (EDID)

LIVE VIDEO RESOLUTIONS (ENCODE/DECODE)

- 176 x 144@30, 60 fps (QCIF)
- 352 x 288@30, 60 fps (CIF)
- 512 x 288@30, 60 fps (w288p)
- 576 x 448@30, 60 fps (448p)
- 768 x 448@30, 60 fps (w448p)
- 704 x 576@30, 60 fps (4CIF)
- 1024 x 576@30, 60 fps (w576p)
- 640 x 480@30, 60 fps (VGA)
- 800 x 600@30, 60 fps (SVGA)
- 1024 x 768@30 fps (XGA)
- 1280 x 768@30 fps (WXGA)
- 1280 x 720@30, 60* fps (720p30/60)
- 1920 x 1080@30 fps (1080p30)*

720p30 from 768kbps

720p60 from 1152kbps**

1080p30 from 1472 kbps**

AUDIO STANDARDS

G.711, G.722, G.722.1, 64 kbps MPEG4 AAC-LD

AUDIO FEATURES

- CD-Quality 20KHz Mono
- 1 x Acoustic Echo Canceller
- Automatic Gain Control (AGC)
- Automatic Noise Reduction
- Active Lip Synchronization

AUDIO INPUTS (4 INPUTS)

- 2 x Microphone, 4 pin MiniJack
- 2 x RCA/Phono (mixed to mono)

AUDIO OUTPUTS (3 OUTPUTS)

- 2 x RCA/Phono (dual mono)
- 1 x HDMI (digital main audio)

APPROVALS

EU/EEC

Directive 2006/95/EC (Low Voltage Directive)

-Standard EN 60950-1, 2ed

Directive 2004/108/EC (EMC Directive)

-Standard EN 55022, Class A

- Standard EN 55024

- Standard EN 61000-3-2/-3-3

Warning: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

USA

Approved according to UL 60950-1

Complies with FCC15B Class A

Canada

Approved according to CAN/CSA C22.2 No. 60950-1

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

All specifications are subject to change without notice, system specifics may vary.

All images in these materials are for representational purposes only, actual products may differ.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company.

MTBF PRODUCT RELIABILITY/MTBF

The predicted reliability is expressed in the expected random Mean Time Between Failures (MTBF) for the electronic components based on the Power On Hours:

Power On Hours (POH) > 69 000 hours

Useful Life Cycle > 6 years

ISO 9001 certificate is available upon request

February 2011

* Requires option



On our web site you will find an overview of the worldwide Cisco contacts.

Go to: <http://www.cisco.com/web/siteassets/contacts>

Corporate Headquarters
Cisco Systems, Inc.
170 West Tasman Dr.
San Jose, CA 95134 USA

Disclaimer

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

TANDBERG is now a part of Cisco. TANDBERG® is a registered trademark belonging to Tandberg ASA.